## **SeaStar Solutions Products**

# DUAL CABLE STEERING BRACKET PART NUMBER 308949

PLEASE COMPLETELY READ AND UNDERSTAND THESE INSTRUCTIONS PRIOR TO INSTALLATION TO AVOID DAMAGE TO THE OUTBOARD MOTOR, THE BOAT OR THE ACCESSORY.

PARTS LIST		
ITEM	DESCRIPTION	QUANTITY
1	STEERING CABLE MOUNTING BRACKET	1
2	STEERING CABLE SUPPORT TUBE	= -1
3	ADJUSTMENT NUT	2
4	LOCKING TAB WASHER	2
5	BUSHING	1
6	SEAL	1
7	CABLE CONNECTOR	1
8	3/8 SELF-LOCKING NUT	2
9	3/8 FLAT WÄSHER	3
10	MOUNTING BOLTS	4

NOTE: BOTH GEAR RACKS OR ROTARY STEERING HEADS MUST BE INSTALLED SO THAT BOTH STEERING CABLES WILL BE ROUTED TOGETHER ON THE SAME SIDE OF THE BOAT AND WILL PUSH-PULL TOGETHER. SEE FIGURE 1.




FIGURE 1

GEAR RACK AND ROTARY HEAD CONFIGURATIONS

#### STEERING ARM INSTALLATION




FIGURE 2 STEERING ARM INSTALLATION

A. Install the Steering Arm to the motor Tiller Arm using the inner (rearmost) bolt hole, and torque to specification. Be sure to use the Lock Nut, as shown in the rigging specifications. See Figure 2.






FIGURE 3 CABLE CONNECTOR INSTALLATION

B. Assemble the Cable Connector onto the Steering Arm, as shown in Figure 3.

NOTE
DO NOT TIGHTEN INSTALLATION
TOGETHER AT THIS TIME.

### STEERING CABLE INSTALLATION: CABLES 1 AND 2




FIGURE 4

CABLE 1 INSTALLATION

#### \* CAUTION

Some engines require metric hardware. Make sure the proper size mounting bolt is used.

B. Install the *Bracket* onto the Mounting Boss with the four (4) each *Mounting Bolts* provided, and torque to 100 in.-lbs.




FIGURE 6

CABLE 2 INSTALLATION

A. Lubricate the inside of the engine Tilt Tube, the inside of the Steering Cable Support Tube and the output end of the Cable with a coat of good quality waterproof marine grease. Install Steering Cable Number 1 into the engine Tilt Tube and tighten the Holding Nut. See Figure 4.





FIGURE 5 MOUNTING BRACKET INSTALLATION

C. Slip the large Support Tube Nut and Locking Tab Washer over Cable Number 2. Apply a coat of marine grease to the Cable End. Insert the Cable thru the Mounting Bracket holes WITHOUT the Support Tube installed. Turn the Steering Wheel to extend the Cables to their full length, then back off 1/4 turn.

See Figure 6.


Page 2 of 4 055001-588




SUPPORT TUBE INSTALLATION FIGURE 7

D. Install the Support Tube onto the extended portion of Cable Number 2 and thru only ONE hole in the Mounting Bracket. Slide the second Large Nut and Locking Tab Washer over the end of the Cable and onto the Support Tube a few turns. Slide the Nylon Bearing and Rod Seal onto the Cable, but NOT INTO THE STEERING TUBE AT THIS TIME.

E. Carefully spread both Cables to allow installation of the Cable Connector, but DO NOT TIGHTEN AT THIS TIME. See Figure 8.



CABLE CONNECTOR CONNECTION FIGURE 8



- F. Fully install the Support Tube to the Mounting Bracket with the second Large Nut and Locking Tab Washer. Position the starboard end of the Support Tube so that it is approximately even to the starboard end of the Tilt Tube. See Figure 9.
- G. Tighten the Cable Number 2 Support Tube Nuts at this time, as well as the Cable Holding Nut.
- H. Tighten the three (3) Cable Connector Nuts, torquing to 120 in.-lns. Then back Nuts off 1/4 turn.. Refer to Figure 8.
- I. Insert the Nylon Sleeve into the Steering Tube and slide the Rod Seal onto the end of the Support Tube. Refer to Figure 7.

Page 3 of 4 055001-588

- A. Center the motor.
- B. Loosen the Support Tube Holding Nuts (both ends) approximately 10 turns.
- C. Take up any play in the Cables by pushing the motor slightly in the direction of a turn to starboard.
- D. Tighten the port Support Tube Nut finger tight, then ONE additional turn past that, using a wrench.
- E. Tighten the starboard Support Tube Nut to 35 ft. lbs., and bend the locking tabs on the Locking Tab Washers over onto the Mounting Bracket or Nut, as shown in Figure 9.

