

MEMBER  
**ABYC**  
Setting Standards for Safer Boating

50<sub>13</sub>

FIFTY POINT THREE  
ISO 9001

OPTIMUS EPS  
BY SEASTAR

**BAYSTAR**™

**SEASTAR**™

## INSTALLATION MANUAL

### ELECTRONIC POWER STEERING (EPS)

[www.seastarsolutions.com](http://www.seastarsolutions.com)



**OPTIMUS EPS**  
BY **SEASTAR**™

---

5000 Series Electronic Power Steering  
for Large Inboard Powered Vessels

---



*Before you do it your way,  
please try it our way*

**©2016 SeaStar Solutions.**

All Rights Reserved. This document, subject matter and all information herein is the sole, exclusive and confidential property of SeaStar Solutions and shall not be disclosed, copied, reproduced or used in whole or in part for any purpose other than as specifically authorized in writing by Marine Canada Acquisition (DBA SEASTAR SOLUTIONS).

---

All information, illustrations and specifications in this manual are based on the latest information available at the time of publishing. The illustrations used in this manual are intended as representative reference views only. Moreover, because of our continuous product improvement policy, we may modify information, illustrations and/or specifications to explain and/or exemplify a product, service or maintenance improvement. We reserve the right to make any change at any time without notice.

---



is a registered trademark of the American Boat & Yacht Council (<http://www.abycinc.org>)

NMEA 2000® is a registered trademark of the National Marine Electronics Association.

Optimus, Optimus 360, SeaStar, and BayStar are all trademarks of SeaStar Solutions.

---

**California  
Proposition 65 Warning**

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and reproductive harm.

Wash hands after handling.

Thank you for choosing an Optimus™ Electronic Power Steering (EPS) System. You have chosen a state of the art steering system that will provide years of effortless and trouble free steering performance.

## About this Book


---

This book will show you how to install the base Optimus EPS steering system to a vessel powered by inboard engines. Use it in conjunction with the Optimus Setup and Configuration Guide (Book 65).

Deliver this book to the customer when the installation is complete.

## Notice to the Installer

---

Throughout this publication, Dangers, Warnings and Cautions (accompanied by the International Hazard Symbol ) are used to alert the user to special instructions concerning a particular service or operation that may be hazardous if ignored or performed incorrectly or carelessly. **Observe Them Carefully!**

These safety alerts alone cannot eliminate the hazards that they signal. Strict compliance with these special instructions during installation, operation, and maintenance, plus common sense operation, are important measures to prevent accidents.

---

### DANGER

**IMMEDIATE HAZARDS WHICH, IF NOT ACTED UPON, WILL RESULT IN SEVERE PERSONAL INJURY OR DEATH.**

---

### WARNING

**HAZARDS OR UNSAFE PRACTICES WHICH, IF NOT ACTED UPON, COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH.**

---

### CAUTION

**Hazards or unsafe practices which COULD result in minor injury or product or property damage.**

---

### NOTICE

*Information which is important to proper use or maintenance, but is not hazard-related.*

# ABBREVIATIONS

The following abbreviations are used in this manual:

---

ABYC	American Boat & Yacht Council
AUX	Auxiliary
BAT	Battery
CAN	Controller Area Network
CAN Bus	Controller Area Network (data) bus. (A harness of wires that carry digital signals and power between electronic modules)
ENG	Engine
EPS	Electronic Power Steering
FT-LB	Foot Pounds
GND	Ground
HI	High
IN-LB	Inch Pounds
LED	Light Emitting Diode
LO	Low
MPH	Miles Per Hour
NA	Not Applicable or Not Available
N/C	No Connection
Nm	Newton Meters
NMEA	National Marine Electronics Association
NMEA 2000®	A protocol for digital communication on a CAN Bus
PCM	Pump Control Module
RFU	Rudder feedback unit. This is the position sensor on the SmartCylinder. Sometimes called a rudder reference unit.
RPM	Revolutions Per Minute
STBD	Starboard (right when facing forward)
SW	Switch
WOT	Wide Open Throttle

***Note: Some abbreviations not listed here may be found in their respective sections.***



# INDEX

<b>Abbreviations .....</b>	<b>ii</b>
<b>1.0 Safety Information .....</b>	<b>1-1</b>
<b>2.0 System Overview .....</b>	<b>2-1</b>
2.1 System Description .....	2-1
2.2 Optimus EPS System Diagrams .....	2-2
<b>3.0 Installation Overview .....</b>	<b>3-1</b>
3.1 Important Information/Technical Support Contact .....	3-1
3.2 Installation Summary .....	3-1
<b>4.0 Planning.....</b>	<b>4-1</b>
4.1 Required Parts .....	4-2
4.2 Plan Your Component Placement .....	4-3
4.2.1 <i>Electronic Helm(s)</i> .....	4-3
4.2.2 <i>CANtrak Display</i> .....	4-5
4.2.3 <i>Pump Control Module (PCM)</i> .....	4-6
4.2.4 <i>Power Steering Pump</i> .....	4-8
4.2.5 <i>SmartCylinders</i> .....	4-9
4.2.6 <i>Steering Service Valves</i> .....	4-10
4.2.7 <i>Circuit Breakers</i> .....	4-10
4.3 Plan Your Connections .....	4-11
4.3.1 <i>Hydraulic Hoses</i> .....	4-11
4.3.2 <i>Power Connections</i> .....	4-12
4.3.3 <i>Ignition Connection</i> .....	4-14
4.3.4 <i>Engine RPM Source Connection</i> .....	4-14
4.3.5 <i>Autopilot Connection (Optional)</i> .....	4-14
4.4 Diagram.....	4-16
<b>5.0 Component Installation.....</b>	<b>5-1</b>
5.1 Helm(s).....	5-1
5.1.1 <i>EPS Front Mount Helm (EH1512)</i> .....	5-2
5.1.2 <i>EPS Sport Plus Tilt Helm (EH1532)</i> .....	5-3
5.1.3 <i>EPS Classic Tilt Helm (EH1552)</i> .....	5-4
5.1.4 <i>EPS Rear Mount Helm (EH1572)</i> .....	5-5
5.1.5 <i>EPS Rear Mount Helm (EH1592) 1" Straight Shaft</i> ...	5-6
5.2 CANtrak Display .....	5-7
5.3 PCM and Power Steering Pumps .....	5-8
5.3.1 <i>PCM Recommended Mount Hardware</i> .....	5-8
5.3.2 <i>PCM Mounting Considerations</i> .....	5-9
5.3.3 <i>Power Steering Pump Mounting Considerations</i> ...	5-10
5.3.4 <i>Power Steering Pump Mounting Hardware</i> .....	5-11
5.3.5 <i>Integrated Steering Service Valve</i> .....	5-12
5.4 SmartCylinder Installation .....	5-13
5.4.1 <i>EC5810 &amp; EC5850 Inboard Cylinders</i> .....	5-13
5.5 Plumbing the System .....	5-16
5.5.1 <i>Hose Labels</i> .....	5-17
5.5.2 <i>Hose Installation</i> .....	5-18
5.5.3 <i>Hose Fitting Reorientation (if required)</i> .....	5-19
5.6 Connecting the SmartCylinder .....	5-20

<b>6.0 Networks and Wiring .....</b>	<b>6-1</b>
6.1 Network Diagrams.....	6-1
6.2 Harness Connections .....	6-3
6.2.1 Connecting the Helm and CANtrak Display.....	6-3
6.2.2 Connecting a Second Station .....	6-5
6.3 Power Wiring .....	6-6
6.3.1 PCM Wiring .....	6-6
6.3.2 PCM Wiring Strain Relief .....	6-8
6.4 Ignition Sensing .....	6-9
6.4.1 Ignition Splicing.....	6-10
6.5 Engine RPM Source .....	6-11
6.5.1 NMEA 2000 CAN Bus .....	6-11
6.5.2 J1939 Network Connection .....	6-12
6.5.3 Analog Tachometer.....	6-13
6.6 Autopilot Connection (Optional) .....	6-13
6.7 Buzzer Kit (Optional) .....	6-14
<b>7.0 System Setup and Configuration.....</b>	<b>7-1</b>
7.1 First-Time Power-up of the System .....	7-1
7.2 Initial Setup .....	7-1
7.3 Steering Setup .....	7-3
7.4 Configuration (Inboard Only) .....	7-3
7.5 Purge the Steering System.....	7-6
7.6 Calibrate the SmartCylinders.....	7-9
7.7 Align Rudders (Inboard & Sterndrive Only) .....	7-1
7.8 Set Proportional Sensitivity .....	7-13
7.9 Steering Parameters.....	7-14
7.9.1 Speed Sensitive Steering .....	7-14
7.9.2 Low and High Speed Thresholds .....	7-14
7.9.3 Steering Parameter List.....	7-15
7.9.4 Set Rudder Limits .....	7-16
7.9.5 User Permissions .....	7-17
7.10 Generic Setup Twin Cylinder Inboard .....	7-17
7.10.1 Devices Menu Settings.....	7-17
7.10.2 Initial Set Up Menu Settings .....	7-17
7.10.3 Settings Menu Settings .....	7-19
<b>Appendix A – Mounting Templates .....</b>	<b>A-1</b>
A.1 Helm Templates .....	A-1
A.1.1 Front Mount Helm (EH1510/EH1512).....	A-1
A.1.2 Sport Plus Tilt Helm (EH1530/EH1532) .....	A-3
A.1.3 Classic Tilt Helm (EH1550/EH1552).....	A-5
A.1.4 Rear Mount Helm (EH1570/EH1572) .....	A-7
Rear Mount Helm (EH1592) 1" Straight Shaft.....	A-8
A.2 CANtrak Display .....	A-9
A.3 PCM Mounting Dimensions .....	A-11
A.4 Power Steering Pump Mounting Dimensions .....	A-12
<b>Appendix B - Bolt Torque Specifications .....</b>	<b>B-1</b>
<b>Warranty .....</b>	<b>B-3</b>

# 1.0 SAFETY INFORMATION

## WARNING

**THE SAFETY INFORMATION PROVIDED HERE IS INTENDED TO INFORM YOU OF THE DANGERS THAT MAY BE PRESENT BEFORE, DURING, AND AFTER INSTALLATION. IT IS CRITICAL THAT YOU READ AND UNDERSTAND THIS INFORMATION.**

Safe operation of the steering system depends upon proper installation and maintenance of the system, and the common sense, safe judgment, knowledge, and expertise of the operator. Every installer and operator of the steering system should know the following requirements before installing or operating the steering system. If you have any questions regarding any of these warnings, contact SeaStar Solutions.

### **Before installation**

1. Read and understand all installation and user's manuals provided with the steering components.
2. Ensure that all components required to complete the installation are on hand (including hoses, fittings, oil, and the proper tools).
3. SeaStar and Optimus components are highly engineered and safety tested to ensure system integrity. DO NOT substitute any component. Substitution with non-SeaStar or non-Optimus components may compromise system safety, performance, and reliability.
4. DO NOT use a wheel-mounted, coiled cord trim switch. The cord can wrap tight around the steering wheel shaft and inhibit steering.

### **During Installation**

1. Install system components as directed in this manual. Some component parts and kits (such as hoses and fitting kits) are supplied with additional installation instructions—refer also to these instructions.
2. SeaStar and Optimus components are highly engineered and safety tested to ensure system integrity. DO NOT substitute any component. Substitution with non-SeaStar or non-Optimus components may compromise system safety, performance, and reliability.
3. If an instruction is unclear, contradictory, or you are otherwise uncertain how to proceed, do not guess. Call SeaStar Solutions technical support.

### **After Installation**

1. Check that there is no interference between the steering cylinder(s), transom, hull, tiller, tie bar (if applicable) or any other component over the full stroke of the cylinder(s). Steer slowly while performing these checks.
2. Check that the steering cylinder can be fully stroked in both directions, without stretching, chafing rubbing, or kinking of the hydraulic hoses and electrical harnesses.
3. Check that only SeaStar Pro steering hose (1500psi rating) has been used to plumb the system.

---

### **Prior to every use**

Perform a system inspection as outlined below.

1. Check steering fluid level in all steering pumps.
2. Verify immediate steering response when turning steering wheel(s).
3. Inspect all steering hoses, fittings, mechanical cables, and electrical harnesses for wear, kinks, or leaks.
4. Check for binding, loose, worn or leaking steering or shift/throttle control components.
5. Verify that no alarms or warnings are shown on the CANtrak display.

---

### **⚠ WARNING**

**DO NOT OPERATE BOAT IF ANY COMPONENT IS NOT IN PROPER WORKING CONDITION.**

---

### **During use**

1. WEAR A COAST GUARD-APPROVED PERSONAL FLOTATION DEVICE (PFD).
2. ATTACH ENGINE SHUT-OFF CORD (LANYARD) TO YOUR PFD.
3. Never allow anyone who is not familiar with the operation of the steering system to operate the boat at any time.
4. If boat is equipped with multiple helms, ensure that only one is used at a time.
5. Know and adhere to all applicable federal, state, and municipal laws and regulations that govern boating in your area.

---

### **⚠ WARNING**

**DO NOT OPERATE BOAT IF ANY COMPONENT IS NOT IN PROPER WORKING CONDITION.**

---

### **After use**

If the SmartCylinder(s) have been exposed to salt water, rinse them thoroughly using only fresh, clean water.

DO NOT rinse the PCM, pumps, actuators, or any other component of the Optimus system.

DO NOT use acetone, or cleaners containing ammonia, acids, or any other corrosive ingredients on any Optimus components.

---

### **⚠ WARNING**

**Failure to comply with any warning, notice or caution may lead to loss of steering control resulting in a collision and/or ejection from the boat leading to property damage, personal injury and/or death.**

# 2.0 SYSTEM OVERVIEW

## 2.1 System Description


Optimus EPS is a steer-by-wire system that replaces a traditional hydraulic helm with electronic components that communicate over a serial data network. This state-of-the-art system incorporates many advanced features to make it safe and reliable. These features include redundant sensors, fault-tolerant communications, extensive self-monitoring, and fault communications to notify and advise the operator in case of a system fault.

The Optimus EPS system consists of several major components, listed below. Refer to figure 2-1 and figure 2-2 to see these components in a schematic system diagram.

### CAN Networks


CAN (controller area network) is a serial network protocol that is widely used in marine and automotive control systems. Each device (node) on the network can send and receive data using specially formatted messages. The ability to reliably communicate data between devices is what enables the steer-by-wire functionality of Optimus EPS. Optimus EPS uses up to three independent CAN networks, designated CAN1, CAN2, and CAN3.

- CAN1 is a low-speed, fault-tolerant network with redundant power wiring. It is used for safety-critical communications.
- CAN2 is a high-speed network that is well-suited for non-critical tasks such as passing data to and from the CANtrak display.
- CAN3 is a public network using the NMEA 2000 protocol. The Optimus system broadcasts public messages onto this network, and can also monitor the network for engine RPM. Use of this network is optional.




### Electronic helm

The helm converts steering wheel movement into digital messages that are sent over CAN1 to the pump control module (PCM). A system of friction plates in the helm allow the steering effort to be adjusted according to a setpoint received from the PCM. (A steering wheel is not included with the Optimus EPS system.)




### CANtrak display

The CANtrak display is a small color LCD that displays system status and fault information to the operator. It is also used to make changes to user-adjustable steering settings. Authorized installers have access to additional menus with system setup and calibration tools.



### Pump control module (PCM)

The PCM receives wheel movement messages from the helm(s) and operates the hydraulic steering pumps to steer the vessel as required. The PCM uses position feedback from the SmartCylinders for precise steering control and fault detection. The PCM can also respond to inputs from a certified autopilot system.



### **Power steering pump**

The power steering pump supplies pressurized fluid to the SmartCylinder in order to steer the boat. The PCM controls a pair of DC motors that drive small gear pumps. The pump assembly has an integral fluid reservoir and pressure relief valves.

The steering pump has an integral service valve that can be opened to bypass the pump and allow the rudders to be manually repositioned. They are used for service or in the case of an emergency.

### **SmartCylinders**

The SmartCylinder is a hydraulic steering cylinder fitted with a magnet and a position sensor. A SmartCylinder can steer two rudders connected with a tiebar (not supplied by SeaStar) or steer two rudders with two individual SmartCylinders.

### **Remote-mounted steering service valve (optional)**

When the service valve on the power steering pumps are not easily accessible these optional remote-mounted valves can be installed in a convenient location.

## 2.2 Optimus EPS System Diagrams

The system diagrams shown on the following pages are meant for illustrative purposes only.

Do not use these diagrams as installation schematics.






Figure 2-1. Optimus EPS system diagram, single station.




Figure 2-2. Optimus EPS system diagram, dual station, single cylinder.






Figure 2-3. Optimus EPS system diagram, single station, twin cylinder.




Figure 2-4. Optimus EPS system diagram, dual station, twin cylinder.

## 3.0 INSTALLATION OVERVIEW

### 3.1 Important Information/Technical Support Contact

---

To ensure proper installation and maintenance of this steering system, please note the following:

- Installation must be performed by a SeaStar Solutions authorized installer.
- Read and understand all installation instructions provided with the system and its components before starting the installation.
- Read and understand all the safety information noted in this manual and all other installation instructions..

If you need technical assistance, or wish to report an error in our documentation, please contact SeaStar Solutions technical support:

#### **Technical Support**

Web: [www.seastarsolutions.com](http://www.seastarsolutions.com)

E-mail: [seastar@@seastarsolutions.com](mailto:seastar@@seastarsolutions.com)

Phone: 604.248.3858

Fax: 604.279.2202

### 3.2 Installation Summary

---

There are several stages in the installation of the Optimus EPS system, listed below. By reviewing this summary you will better understand each step in the context of the entire installation.

#### **Planning (Section 4)**

- Acquire a general understanding of the system and its various components.
- Check that the equipment supplied is available and correct.
- Establish suitable locations for each component.
- Plan the cabling and the hose connections.
- Consider the power connections to the battery and the breaker location. All wiring should be done to ABYC standards.
- Consider where the ignition and tach sources will come from.
- Verify that you have a dealer setup kit for purge & calibration.
- Make a diagram of the system as it pertains to the particular boat installation.

### **Component Installation (Section 5)**

- Mount the helm.
- Mount the CANtrak.
- Mount the pump control module (PCM) and the power steering pump.
- Install the SmartCylinder.
- Install the remote service valves (if necessary).
- Install the hoses.

### **Networks and Wiring (Section 6)**

- Review network diagrams
- Install network tees.
- Connect network harnesses.
- Install circuit breakers and run the power wires.
- Connect ignition wires.
- Connect engine RPM source.
- Connect autopilot if required.

This concludes all the physical installation steps up to the point when the system is powered on. The setup and commissioning of the Optimus EPS system is covered in the Setup and Configuration Guide.

# 4.0 PLANNING

---

Proper planning is critical to a successful installation. This section will step you through the key planning activities:

- Review each of the major components and consider where to place them, keeping in mind the various mounting restrictions.
- Check that the harness connections can be made without violating any of the cabling restrictions. Determine if the available harnesses are sufficient or if it is necessary to order any additional harnesses or cabling components.
- Ensure that you understand the CAN network requirements and have the required components available. Review Appendix B for important information about planning the CAN network.
- Plan the location of the breakers and the connections to the batteries, keeping in mind the ABYC requirements. Confirm the required breakers are at hand. Make sure that sufficient wire of the correct gauge is available with the correct termination hardware and tie straps.
- Review the required hoses and fittings and check that all are available.
- Document the information on the system diagram in section 4.4.

---


## NOTICE

*It is highly recommended that a complete review of Section 4 is done in order to assemble the appropriate materials and ensure that proper installation techniques are understood.*

## 4.1 Required Parts


---

Check that following parts are available for the installation:




**Helm**

*One per helm station.*




**CANtrak Display**

*One per helm station.*




**Pump Control Module (PCM)**

*One PCM is required.*



**SmartCylinder**

*One cylinder is required with the EPSK1300 system.  
Two cylinders are required with the EPSK1500 system.*



**Power steering pump**

*One pump is required with the EPSK1300 system.  
Two pumps are required with the EPSK1500 system.*

---

Figure 4-1.

Other parts required (not shown):

- SeaStar Pro Steering Hoses
- SeaStar Electronic Power Steering Fluid (Green/blue color)
- Dealer Installation Kit and Purge Hose
- Electrical harnesses and wire(s) (some wire[s] not supplied by SeaStar Solutions)
- Circuit breakers (not supplied by SeaStar Solutions)
- Steering wheel (not supplied by SeaStar Solutions)

## 4.2 Plan Your Component Placement

Review the detailed information for each of the following components and determine where they will be located on the boat. Pay particular attention to the harness length information, as this may impact the choice of component locations. During this process, confirm that the correct harness lengths are available.

### 4.2.1 Electronic Helm(s)

The helm is an electronic unit and send signals to the Pump Control Module (PCM) via an electrical harness supplied with the system. One helm is required at each station (the system supports up to three stations).

There are five helm styles available; different style helms may be used at different stations. Standard helm shaft size is 3/4", but a 1" shaft is available in the rear mount configuration.

Mounting templates can be found in Appendix A.

#### **⚠ CAUTION**

The helm may effect a ship's or the autopilot's compass. For less than one degree of effect keep the EPS helm and the compass a minimum of 24 inches (61 cm) apart.



EPS Front Mount Helm  
Part No. EH1512



EPS Sport Plus Tilt Helm  
Part No. EH1532



EPS Classic Tilt Helm  
Part No. EH1552



EPS Rear Mount Helm  
Part No. EH1572



EPS Rear Mount Helm  
Part No. EH1592  
(1" Straight Shaft)

Figure 4-2.

## ⚠ CAUTION

**Total harness length CANNOT exceed 120 feet. Do not use more than three harnesses between devices.**

The harness length from the PCM to the farthest helm may not exceed 120 total feet. Harnesses are available in 6-foot increments up to 36 feet, with an available 36 foot extension. Under no circumstances should you use more than two extensions (for a total of three harnesses) between consecutive devices.

CAN1 HARNESS – HELM TO PCM		
At least one harness per helm station is required.		
DESCRIPTION	LENGTH, FT (m)	PART No.
Harness, EPS, H4, 6 PIN FCI	3 (0.9)	CM20403
	6 (1.8)	CM20406
	12 (3.6)	CM20412
	18 (5.5)	CM20418
	24 (7.3)	CM20424
	30 (9.1)	CM20430
	36 (11)	CM20436
	60 (18.2)	CM20460
Harness, EPS, FTCAN Extension M-F	36 (11)	CM22036
Harness, Wye	2 (0.6)	CM21702
Harness, Coupler M-M	1 (.03)	CM22401

Table 4-1.


## NOTICE

*Every harness connection is a potential failure point. Try to minimize the number of connections in your system and always locate them in dry and protected areas.*


### Single Helm



### Multiple Helm (Preferred Arrangement)



### Multiple Helm (Optional Arrangement)



**Total combined length less than 120'. Maximum six harnesses in entire chain. A wye harness (CM21702) is required.**

Figure 4-3.



## 4.2.2 CANtrak Display

### NOTICE

*A CANtrak display is required at the main helm station, but is optional at secondary control station(s). At a minimum a buzzer should be fitted to the second and/or third station. Buzzer Kit HA5493 with an extension harness is available.*

All CANtrak Displays are identical and can be used at any station. The display must be easily visible from the helm station. The display may be located in any position but if it is exposed to weather it should be installed on a sloped surface so water does not collect on the screen. The CANtrak connects to the helm with an included 3 foot (0.9m) harness (CM20403). Ensure the display is close enough to the helm for the harness to reach without strain. If necessary, you can extend the harness using a union harness (CM22401) and an extension harness from table 4-1.


A mounting template can be found in Appendix A.

### NOTICE


*Updating the CANtrak display software requires insertion of a USB drive in the rear of the display. Consider this requirement when deciding on a mounting location.*



# DO



Mount vertical to hull or wall



Mount at an angle less than 60°

# DO NOT




Figure 4-4.

### 4.2.3 Pump Control Module (PCM)

The PCM should be mounted in a cool, dry area and must be mounted in such a way that the three foot harnesses supplied with the power steering pump reaches the PCM. The harnesses *must not* be extended. Do a dry fit, with the leads properly run through the strain relief plate to verify the harnesses will reach.

Each PCM has two independent power feeds (port cranking battery and starboard cranking battery), each of which must be connected to a power source. See section 4.3.2 for more information.

Mounting dimensions can be found in Appendix A.

#### ⚠ CAUTION

**Do not use Automatic Power Selectors (APS) or selector diodes of any kind on the PCM power or ignition wires. This functionality is already built into the PCM.**

#### ⚠ WARNING

**ALL ELECTRICAL CONNECTIONS AND HARNESS MUST COMPLY WITH ABYC WIRING STANDARDS, BE RATED FOR 105°C (221°F), AND COMPLIANT WITH SAEJ1128.**




Figure 4-5 Part No. EM1200.

Each pump must be connected to the PCM as shown in figure 4-5. In a twin cylinder system two WYE harnesses (CM20035) are also required, see figure 4-6. These harnesses allow the two motor harnesses from one pump to be connected to one side of the PCM. The RFU harness of the cylinder that is connected to the pump must be plugged into the same side of the PCM that the pump is connected to.





Figure 4-6. Wye harness (part # CM20035) used to connect pump to PCM.


## ⚠ WARNING

**MAKE SURE THAT ALL UNUSED PORTS HAVE SEALING PLUGS.**

# DO



**Mount vertical (parallel) to hull or wall, plus or minus 15°**



# DO NOT






Figure 4-7.

## 4.2.4 Power Steering Pump

### ⚠ CAUTION

**Pump harnesses must not be extended.**

### NOTICE

*Due to material variability, fitting installation torque differs between the power steering pump and the steering cylinder. Be sure to use the correct installation torque to avoid irreparable damage to the pump housing or cylinder body when installing an ORB fitting.*

### NOTICE

*Hose fittings can be relocated to plugged ports if required. (See figure 4-8, item 1 and 2.) Torque hose fittings to 18 ft-lb (24 Nm) and plugs to 50 in-lb (6 Nm).*

*You can also install 90° fittings (Kit # HF6004) for additional hose routing flexibility.*

The power steering pump provides the fluid flow to move the Smart-Cylinder. The pump is designed to be floor mounted in a dry location adjacent to the PCM, such that the 3 foot (0.9 m) pump harnesses can be connected with proper strain relief (see figure 6-9). Conduct a test fit before permanently mounting the pump.

The power steering pump makes a moderate amount of noise when operational. Select a location that will minimize the noise in the passenger area; typical locations include the engine room or in the lazarette adjacent to the steering cylinder. The location of the pump will have the most impact on the overall ease of installation and long term system maintenance so take time deciding on the best location. Mounting dimensions can be found in Appendix A.

Some considerations:

- It is very important which pump harness plug's into which port. The PCM has a red decal on the left to indicate the port side and a green decal on the right to indicate starboard side. Ensure the correct pumps are installed in the appropriate sides.
- Maximum hose length between pump and cylinder is 40 feet (12.2 m). Longer runs will require 3/8" copper/stainless steel tubing suitable for a maximum working pressure of 2000 psi (not supplied by SeaStar).
- It is easier to run communications harnesses than hydraulic hoses and heavy power wires.
- The operator will need to check the steering fluid level in the power steering pump on a regular basis.
- The steering service valve *must* be placed in an area with light and visibility, easily accessible to the operator in case of emergency. If you can't locate the pumps in this way use the remote service valve kit, HA5480, as shown in section 4.2.6.
- Service and maintenance operations will be performed for the life of the boat. The installation is performed once.




Figure 4-8.

## 4.2.5 SmartCylinders

### ⚠ CAUTION

Ensure that there are no pumps, motors, or other magnetic fields, too close to the cylinder because they may affect the position feedback signal. The minimum recommended distance is 12" (30 cm).

The SmartCylinder moves the tillers and supplies a feedback signal that tells the PCM where the rudders are positioned. The SmartCylinder connects to the power steering pump by means of two hoses, and connects to the PCM with an electrical harness.

It is very important that the hydraulic hoses and harness are installed in such a way that gives the cylinder full travel without kinking or snagging on an obstruction.

Refer to table 5-2 on page 5-15 for mounting dimensional information.




Figure 4-9.

The EC5810 SmartCylinder (9.5" stroke) comes with an 18 foot (5.5 m) electrical harness and the EC5850 (12" stroke) comes with a 30 foot (9.1m) electrical harness, which connect to the PCM. There are four lengths of extension harnesses available, if required. Up to two extension harnesses may be added to each SmartCylinder harness for a maximum combined harness length of 48 feet (14.63 m). Take care to locate the harness connections in dry areas (or in a junction box) and provide strain relief on either side of each connection.

### ⚠ CAUTION

SmartCylinder sensor harness and extensions must not exceed 48 feet (14.63 m).

DESCRIPTION	LENGTH, FT (m)	PART NO.
SmartCylinder Harness Ext. EPS, H9	6 (1.8)	CM20906
	12 (3.6)	CM20912
	18 (5.5)	CM20918
	30 (9.1)	CM20930

Table 4-2.

### ⚠ WARNING

**THE SMARTCYLINDER ELECTRICAL HARNESS MUST BE PROPERLY SECURED. SEE SECTION 5.6.**

## 4.2.6 Steering Service Valves

The steering service valves are integrated with the power steering pumps. When open they allow the rudders to be manually repositioned, and are used for maintenance or in case of emergency. The pump must be installed so that the valve is accessible and visible to the operator. The supplied decal (figure 5-13) must be applied in a visible location near the service valve.

If you can't install the pumps in such a way that the valves aren't accessible, use the remote-mounted service valve kit HA5480 (one per steering cylinder). These service valves can be mounted in a convenient location. You will require an additional pair of hydraulic hoses for each remote service valve.

Turn the knob fully counterclockwise (about 3 turns) to open the service valve, and clockwise to close. Turn just until you feel a firm stop – do not use tools or overtighten.

### **⚠ WARNING**

**DO NOT OPEN THE SERVICE VALVE WITH THE ENGINE(S) RUNNING.**




Figure 4-10. Service valve location.

## 4.2.7 Circuit Breakers

A circuit breaker must be provided by the installer for each of the two PCM power feeds. See section 4.3.2 for the required circuit breaker rating.

Use only circuit breakers designed for marine use, and with corrosion-resistant, stainless steel connection hardware.

Refer to ABYC wiring standards for all wiring best practices.

## 4.3 Plan Your Connections

At this point of the planning process the location of all major components should be established. Now it is time to review and plan your hydraulic and electrical connections.

### 4.3.1 Hydraulic Hoses

#### **⚠ WARNING**

**THE OPTIMUS EPS SYSTEM REQUIRES THE USE OF KEVLAR REINFORCED HOSES (SEASTAR PRO) ONLY. DO NOT USE EXTRUDED NYLON TUBING, STANDARD SEASTAR (1000PSI) HOSE OR ANY OTHER MANUFACTURERS' HOSE.**

SeaStar Pro steering hoses are available in kits containing two equal length hoses. Determine the length of the required hoses from each the pump to the SmartCylinder, and check that you have the proper hoses available.

If you are using remote-mounted service valves (HA5480) you will need two sets of hoses: one pair from the pump to the service valve and a second pair from the service valve to the cylinder.

Consider the following when planning your hose routing and determining the required lengths:

- Maximum hose length between pump and cylinder is 40 feet (12.2 m). Longer runs will require 3/8" copper/stainless steel tubing suitable for a maximum working pressure of 2000 psi (not supplied by SeaStar).
- The cylinder body moves slightly as it steers. Ensure there is enough slack in the hose routing to avoid any binding, chafing, rubbing, or kinking.
- Minimum bend radius on the hose is 3.5". Never route the hoses in such a way that they can kink.
- Hoses should be secured along their routing path whenever possible, and should not be allowed to hang free in any area where they may become a safety hazard. SeaStar Solutions recommends the use of a rigging tube, PVC piping, or conduit for the safe installation and protection of the steering hoses.
- Do not install hoses in such a way that they may become exposed to hot engine components, such as manifolds or exhaust components.
- Do not install hoses where they may be exposed to corrosive acids, such as those that may be found at battery connection points, or where they may be exposed to battery fumes.

Table 4-3 shows the available hose kits. Each kit comes with two hoses. You can choose from brass or stainless steel hose end fittings.

KIT PART No.	DESCRIPTION	FITTINGS
H057XX	SeaStar Pro hose kit	Brass
H057XXSS	SeaStar Pro hose kit, SS	Stainless Steel
<i>XX denotes hose length in feet, with a leading zero for lengths below 10 feet.</i> <i>Available lengths:</i> <ul style="list-style-type: none"><li>• 2 to 7 feet in 1 foot increments (e.g. for a 3 foot hose kit, order H05703)</li><li>• 8 to 30 feet in 2 foot increments</li></ul>		

Table 4-3.

## 4.3.2 Power Connections

All system wiring and power connections must be made to ABYC standards. See *ABYC E-11 AC and DC Electrical Systems on Boats*.

The Optimus EPS system for large inboard vessels is generally used with a 24V DC power source. For single cylinder applications, it is possible to utilize either a 12V or 24V DC power source. If a 12V power source is utilized, the System Voltage parameter must be set accordingly in the software.

### Typical Source Connections

- Direct to the batteries.
- To battery switches. *Never* switch the negative wire.
- To a bus bar or power distribution panel. Ensure that the wire size from the bus to the batteries is sufficient to handle the peak current of *all* accessories connected to the bus. In general, buses that supply power to vessel electronics such as radar and GPS are usually not acceptable power sources for the EPS system.

ABYC standards require that all wires carrying positive voltage must have a circuit protection device within 7" of the power source. Use a circuit breaker designed for marine use, with the rating shown in Table 4-4.

In some installations the circuit breaker may need to be located more than 7" from the power source. In this case an additional protection device (breaker or fuse) must be located within 7" of the battery to protect the intervening wire. The device must be rated based on wire size, and is usually of a slightly higher current rating than the breaker. Be sure to factor in the entire wire length from PCM to source when selecting wire size. Refer to ABYC E-11 for more details.

See figure 4-11 for source connection examples.

### NOTICE

*ABYC standards require that the negative terminals of all batteries on the vessel be connected together. See ABYC E-11 for more information.*

### Wire Type and Sizing

Use wire with red insulation for the positive connections, and wire with black or yellow insulation for the negative connections.

The positive and negative power wires are frequently routed along different paths. For each wire, determine the length required to connect from the PCM to the power source or ground, then select the correct wire size from Table 4-4.

WIRE LENGTH FROM PCM TO POWER SOURCE		MINIMUM AWG (mm <sup>2</sup> )		
		EPSK1300 12V System Single EC5810 or EC5850 Cylinder	EPSK1300 24V System Single EC5810 or EC5850 Cylinder	EPSK1500 24V System Twin EC5810 or EC5850 Cylinder
0 – 9.8 feet	0 – 3.0 meters	6 (16)	10 (6)	6 (16)
9.9 – 14.7 feet	3.1 – 4.5 meters	4 (25)	10 (6)	4 (25)
14.8 – 24.6 feet	4.6 – 7.5 meters	2 (35)	8 (10)	2 (35)
CIRCUIT BREAKER RATING		60A	30A	60A

Table 4-4.



## Examples




Figure 4-11. Examples.

### Example 1 – 24 volt, twin cylinder system

The negative harness is 4' (1.2 m) and according to the table you can use 6 AWG (16 mm<sup>2</sup>) wire. The positive harness is 6' (1.8 m) and requires a circuit protection device within 7" (18 cm) of the power source. The total length is still below 9.8' (3 m) so again 6 AWG (16 mm<sup>2</sup>) wire can be used.

### Example 2 – 24 volt, twin cylinder system

The negative wire is going from the PCM to a good ground bus. The negative wire is 15' (4.6 m) long and the table indicates that 2 AWG (35 mm<sup>2</sup>) wire is required. The positive wire is 20' (6.1 m) long and goes from the breaker to the PCM. The 7" (18 cm) run from the battery switch to the breaker must be added, resulting in a total length of 20'-7" (6.3 m). Checking the table results in a 2 AWG (35 mm<sup>2</sup>) wire for this connection.

### 4.3.3 Ignition Connection

The EPS system requires an ignition signal at the PCM to “wake up” the steering system. Review the instructions in section 6.4 and:

- plan how you will make the connection and where you need to install wire splices.
- determine the parts (e.g. butt splices) and tools you will require.
- it is common practice to wake up the Optimus steering on key on. Determine a position on the ignition system that remains live both on key on and during cranking of engines.

### 4.3.4 Engine RPM Source Connection

The EPS system requires an engine RPM input to support the speed-sensitive functionality of the system. Engine RPM can come from three sources: an NMEA2000 network, a J1939 engine network, or analog pulse signal from alternator, flywheel sensing or propeller shaft rotations max pulses per rev is 12. Review the instructions in section 6.5 and:

- determine which source you will use.
- if using an existing NMEA2000 network, determine if you need an additional tee (CM10060) and/or extension harness (section 4.2.2).
- if creating a dedicated NMEA2000 network, be sure that you have the kit (HA5492) and an engine gateway.
- if using an analog tachometer, determine the parts and tools you require.

### 4.3.5 Autopilot Connection (Optional)

The Optimus EPS system can take steering commands from compatible autopilot units through a simple CAN2 network connection. Refer to [www.seastarsolutions.com](http://www.seastarsolutions.com) for compatible autopilot systems.

To connect an autopilot you will need to build a small CAN2 network as shown in figure 4-12. See Table 4-5 for available harnesses.

Refer to section 6.6 and the autopilot installation instructions for additional information.




Figure 4-12. Autopilot connection to CAN2 network.

*\* Important Note: If you are using a Simrad SG05 autopilot you must use a power isolating tee such as a Navico 000-12259-001 or a Garmin 010-11580-00.*

---

## DeviceNet Extension Harnesses

Available DeviceNet extension harnesses are listed in Table 4-5. If you need a harness longer than 30 feet (9.1m) you may chain up to three harnesses together for a maximum total length of 90 feet (27.3m).

Every harness connection is a potential failure point. Try to minimize the number of connections in your system and always locate them in dry and protected areas. Use tie wraps or other methods to ensure that nothing is pulling the connection apart.

MICRO-C DEVICENET HARNESS		
DESCRIPTION	LENGTH, FT (m)	PART No.
Micro-C Extension, Male/Female	1 (0.3)	CM10001
	3 (0.9)	CM10003
	6 (1.8)	CM10006
	9 (2.7)	CM10009
	12 (3.6)	CM10012
	16 (4.9)	CM10016
	20 (6.1)	CM10020
	30 (9.1)	CM10030

Table 4-5.

---

### CAUTION

**Do not cut or splice DeviceNet harnesses.**

---

### CAUTION

**Do not connect anything other than SeaStar Optimus components, or SeaStar approved autopilots, to the CAN2 network.**

---

### CAUTION

**If your system voltage is 24V the CAN2 network voltage will also be 24V, which could damage some third-party components.**

## 4.4 Diagram

Use this page to make a complete diagram of the installation. The diagram should be similar to the one in Section 2.2, with the locations and correct harness and hose lengths indicated.

---

Helm area:

PCM/Pump area:

SmartCylinder area:

# 5.0 COMPONENT INSTALLATION

## NOTICE

*Refer to Section 4 – Planning, before proceeding with any part of the installation. This will speed the installation and avoid problems that could occur due to lack of up-front planning.*

## 5.1 Helm(s)

Find the installation diagram for your helm(s) in the following pages. Before beginning the installation, carefully unpack the helm from the box and check that you have all the required hardware shown in the diagram.

Mounting templates for each helm type can be found in Appendix A. Make sure you are using the correct template before drilling or cutting the dash.

A ground strap is provided with each helm. It is critical that this ground strap be installed as described below each installation diagram. If the ground strap is not installed the steering sensor may be damaged by static electricity discharge. This can lead to a failure of the steering system.

We recommend that you note the type and serial number of each helm in the table below. In a multi-station system the serial number will be required during the system setup. The helm type may be useful to the owner in the future.

STATION	HELM TYPE	SERIAL No.
Main	<input type="checkbox"/> Front Mount (EH1512) <input type="checkbox"/> Sport Plus Tilt (EH1532) <input type="checkbox"/> Classic Tilt (EH1552) <input type="checkbox"/> Rear Mount (EH1572) <input type="checkbox"/> Rear Mount, 1" (EH1592)	
Second	<input type="checkbox"/> Front Mount (EH1512) <input type="checkbox"/> Sport Plus Tilt (EH1532) <input type="checkbox"/> Classic Tilt (EH1552) <input type="checkbox"/> Rear Mount (EH1572) <input type="checkbox"/> Rear Mount, 1" (EH1592)	
Third	<input type="checkbox"/> Front Mount (EH1512) <input type="checkbox"/> Sport Plus Tilt (EH1532) <input type="checkbox"/> Classic Tilt (EH1552) <input type="checkbox"/> Rear Mount (EH1572) <input type="checkbox"/> Rear Mount, 1" (EH1592)	

Table 5-1.

## ⚠ WARNING

**ALL HELMS MUST HAVE A GROUND CONNECTION TO THE GROUND, NEGATIVE BUS BAR, OR THE NEGATIVE SIDE OF THE BATTERY TO PREVENT DAMAGE FROM STATIC ELECTRICITY. A GROUND STRAP AND HARDWARE IS PROVIDED WITH EACH HELM.**

**FAILURE TO DO SO MAY RESULT IN LOSS OF STEERING CONTROL, POSSIBLY RESULTING IN PROPERTY DAMAGE, INJURY OR DEATH.**

### 5.1.1 EPS Front Mount Helm (EH1512)




Figure 5-1.

**Install the ground strap** – install one end of the ground strap between the nut and washer on the helm's mounting stud. Connect the other end to ground or negative bus bar or to the battery negative terminal.

#### **⚠ WARNING**

**USE ONLY THE SELF-LOCKING FASTENERS PROVIDED! SUBSTITUTING NON-SELF-LOCKING FASTENERS CAN RESULT IN LOOSENING OR SEPARATION OF EQUIPMENT, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND OR DEATH. DO NOT EXCEED 110 IN-LB, (12NM) TORQUE ON HELM NUTS AND BOLTS.**

## 5.1.2 EPS Sport Plus Tilt Helm (EH1532)




Figure 5-2.

**Install the ground strap** – install one end of the ground strap between the nut and washer of one of the carriage bolts holding the adapter plate to the dash. Connect the other end to ground or negative bus bar or to the battery negative terminal.

### **⚠ WARNING**

**USE ONLY THE SELF-LOCKING FASTENERS PROVIDED! SUBSTITUTING NON-SELF-LOCKING FASTENERS CAN RESULT IN LOOSENING OR SEPARATION OF EQUIPMENT, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND OR DEATH. DO NOT EXCEED 110 IN-LB, (12NM) TORQUE ON HELM NUTS AND BOLTS.**

### 5.1.3 EPS Classic Tilt Helm (EH1552)




Figure 5-3.

**Install the ground strap** – install one end of the ground strap between the nut and washer of one of the carriage bolts holding the adapter plate to the dash. Connect the other end to ground or negative bus bar or to the battery negative terminal.

#### **⚠ WARNING**

**USE ONLY THE SELF-LOCKING FASTENERS PROVIDED! SUBSTITUTING NON-SELF-LOCKING FASTENERS CAN RESULT IN LOOSENING OR SEPARATION OF EQUIPMENT, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND OR DEATH. DO NOT EXCEED 110 IN-LB, (12NM) TORQUE ON HELM NUTS AND BOLTS.**



### 5.1.4 EPS Rear Mount Helm (EH1572)




Figure 5-4.

**Install the ground strap** – install one end of the ground strap between the nut and washer on one of the carriage bolts holding the polished plate to the dash. Connect the other end to ground or negative bus bar or to the battery negative terminal.

#### **⚠ WARNING**

**USE ONLY THE SELF-LOCKING FASTENERS PROVIDED! SUBSTITUTING NON-SELF-LOCKING FASTENERS CAN RESULT IN LOOSENING OR SEPARATION OF EQUIPMENT, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND OR DEATH. DO NOT EXCEED 110 IN-LB, (12NM) TORQUE ON HELM NUTS AND BOLTS.**

### 5.1.5 EPS Rear Mount Helm (EH1592) 1" Straight Shaft




Figure 5-5.

**Install the ground strap** – install one end of the ground strap between the nut and washer on one of the carriage bolts holding the polished plate to the dash. Connect the other end to ground or negative bus bar or to the battery negative terminal.

#### **⚠ WARNING**

**USE ONLY THE SELF-LOCKING FASTENERS PROVIDED! SUBSTITUTING NON-SELF-LOCKING FASTENERS CAN RESULT IN LOOSENING OR SEPARATION OF EQUIPMENT, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND OR DEATH. DO NOT EXCEED 110 IN-LB, (12NM) TORQUE ON HELM NUTS AND BOLTS.**

## 5.2 CANtrak Display


Mount the CANtrak display where it is easily visible from the helm station. A mounting template can be found in Appendix A.

### NOTICE


*On a dual station vessel the CANtrak is optional at the second station. If you don't install a CANtrak at the second station you must install a buzzer kit (HA5493).*

- Mount the display vertically, or within 60 degrees of vertical.
- Ensure adequate ventilation around the unit.
- Ensure that you are able to get to the rear of the unit for harness connections and for insertion of a USB drive when performing a software update.
- **DO NOT** mount parallel to the boat deck, unless the helm is in a completely enclosed wheelhouse where no water can accumulate on the face of the CANtrak.

# DO




Mount vertical to hull or wall



Mount at an angle less than 60°

# DO NOT



Mount parallel to boat deck

Figure 5-6.




Figure 5-7.

## 5.3 PCM and Power Steering Pumps

PCM and the power steering pump must be mounted in close proximity. The three foot harnesses on the pump need to reach the connectors on the PCM without strain, and they cannot be extended. It is not important which pump harness plugs into which pump connection port.




Figure 5-8.


### 5.3.1 PCM Recommended Mounting Hardware

We recommend that you use only stainless steel mounting hardware.

- Fasten at all three mounting points.
- The PCM is designed to fit 1/4" or M6 cap screws or machine screws. Use washers between the screw head and the PCM.
- Through-bolt with nuts and washers on the back the side, or drill and tap into a metal mounting surface.
- You can also use a #14 wood screw and washer.

### 5.3.2 PCM Mounting Considerations

- Mount the PCM to a flat, vertical surface parallel to the wall or hull. It may be mounted no more than 15 degrees from vertical.
- The PCM must be mounted in a cool, dry location.
- Any unused connectors must have a sealing plug installed.



### DO NOT




Figure 5-9.

### 5.3.3 Power Steering Pump Mounting Considerations

- Pump should be mounted in a cool, dry, well ventilated location.
- Pump harnesses are 3' long and must not be extended. Choose pump and PCM mounting locations accordingly.
- Pump is designed to be floor mounted. See Appendix A for mounting dimensions.
- Pump must be mounted so that the oil level indicators and the reservoir are visible and accessible to the operator. Mount the pump so that it is as level as possible when floating at dock. Use shims if necessary. This is to ensure the accuracy of the minimum oil fill level indication.
- The service valve knob must be easily accessible. Ensure there is room around the knob for a user to grasp it and turn it.
- Pump ports are marked 'U' and 'D' and are color coded from the factory to indicate the appropriate cylinder fitting connection.

#### NOTICE

Hose fittings can be relocated to plugged ports if required. (See figure 4-8, item 1 and 2.) Torque hose fittings to 18 ft-lb (24 Nm) and plugs to 50 in-lb (6 Nm).

You can also install 90° fittings (Kit # HF6004) for additional hose routing flexibility.

#### NOTICE

Due to material variability, fitting installation torque differs between the power steering pump and the steering cylinder. Be sure to use the correct installation torque to avoid irreparable damage to the pump housing or cylinder body when installing an ORB fitting.




Figure 5-10.

#### ⚠ WARNING

**THE PUMP MOTOR MAY BE HOT TO THE TOUCH DURING OPERATION. DO NOT MOUNT PUMPS IN AN AREA WHERE FABRICS AND/OR OTHER FLAMMABLE MATERIAL MAY COME IN CONTACT WITH THE PUMP MOTOR. DO NOT COVER.**

---

# D0




Figure 5-11.

## Mounting the power steering pump:

- Pumps must be mounted upright to facilitate oil fill and purge.




Figure 5-12.

---

### 5.3.4 Power Steering Pump Mounting Hardware

We recommend that you use only stainless steel mounting hardware.

- M6 cap or machine screw and washer.
- 1/4" cap or machine screw and washer.
- #14 wood screw and washer (flat bearing surface under screw head only).

### 5.3.5 Integrated Steering Service Valve

The power steering pump has an integrated service valve for maintenance and emergency use. It must be accessible to the operator. If it isn't accessible, you will need to use the remote-mount service valve kit, HA5480.

There is an instruction label on the pump motor. If it is not visible, you must install the label shown in figure 5-13 in a visible location.

**This decal MUST be visible!**




Figure 5-13.



## 5.4 SmartCylinder Installation

### NOTICE

*Before beginning installation make sure that all mounting hardware is available and the tiller arm is clean and free from rust or burrs.*

### 5.4.1 EC5810 & EC5850 Inboard Cylinders

#### ⚠ CAUTION

**If installing rudder stops, ensure that the cylinder(s) reach end of stroke BEFORE rudder stops are engaged.**

Proper cylinder mounting is critical to the successful operation of your hydraulic steering system; misalignment will lead to rapid seal and bearing wear, as well as non-repairable damage.

Figure 5-14 illustrates the correct cylinder alignment, with the cylinder centerline defined by an imaginary line drawn through the tiller arm hole at both hard over positions. Use table 5-2 to determine the required tiller arm length (dimension 'A') for the application, based on required rudder torque and steering angle. Not all possible cylinder mounting configurations are shown, but all share the same key dimensions.

#### ⚠ WARNING

**CYLINDERS MUST BE SECURED WITH THROUGH BOLTS, NOT WITH LAG SCREWS. FAILURE TO DO SO MAY RESULT IN LOSS OF STEERING CONTROL CAUSING PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.**

#### ⚠ CAUTION

**The cylinder bleed fittings must be installed so that they are above the cylinder. If this isn't possible you will need to dismount the cylinder during the purge procedure so that the fittings can be oriented upright. Once the air is removed the cylinder can be reinstalled. Leaving air in the system will drastically affect performance of your steering system.**

**Protect cylinder shafts from nicks and scratches. A damaged cylinder shaft can not be repaired and a new cylinder will need to be purchased.**

### NOTICE

*If a tie-bar is to be used to connect two tillers the tie-bar must be of sufficient size to support the steering loads. DO NOT install tie-bar until after the system has been purged.*


#### Installation Procedure

1. Determine the tiller arm length (dimension 'A') and foot bracket location (dimension 'B') from table 5-2. If the tiller arm length is already set, use figure 5-14 to locate the cylinder, keeping angles X and Y equal over the full stroke of the cylinder.
2. Secure rod end to tiller arm using the supplied hardware. Torque the nut to 120 ft-lb (160 Nm). There must be at least two threads protruding past the nylon locking insert on the nut.
3. Place mounting foot in location indicated in figure 5-15 or figure 5-16 and table 5-2 for desired steering angle. Shim under the feet as necessary to make the cylinder as level as possible. Vertical misalignment will accelerate cylinder wear.

### NOTICE

*In order to obtain a correct push and pull angle between the tiller arm and cylinder, or tiebar and cylinder, the cylinder should be parallel to the transom, tiebar or the keel line (depending on your mounting configuration) when cylinder rod is fully extended (out) or fully retracted (in).*

Attachment to Tiller Arm,  
recommended per ABYC.



CENTER LINE FOR CYLINDER  
MOUNT



Figure 5-14.

**EC5810**




Figure 5-15. EC5810 cylinder.

**EC5850**




Figure 5-16. EC5850 cylinder.

**⚠ CAUTION**

**There is no adjustment for centering the cylinder after installation. Correct mounting is critical at this time.**

Model	Steering Angle							
	50°		60°		70°		80°	
EC5810 9.5" stroke 2.125" Dia.	A	B	A	B	A	B	A	B
	11.27" (286 mm)	7.96" (202 mm)	9.50" (241 mm)	5.98" (152 mm)	8.25" (210 mm)	4.50" (114 mm)	7.40" (188 mm)	3.41" (87 mm)
	56,300 in-lbs (6,360 Nm)		45,400 in-lbs (5,130 Nm)		37,400 in-lbs (4,225 Nm)		31,200 in-lbs (3,525 Nm)	
EC5850 12" stroke 2.125" Dia.	A	B	A	B	A	B	A	B
	14.20" (361 mm)	10.62" (270 mm)	12.00" (305 mm)	8.14" (207 mm)	10.46" (266 mm)	6.32" (161 mm)	9.33" (237 mm)	4.90" (125 mm)
	70,800 in-lbs (8,000 Nm)		57,200 in-lbs (6,460 Nm)		47,100 in-lbs (5,320 Nm)		39,300 in-lbs (4,440 Nm)	

Table 5-2.

**NOTICE**

*The cylinder rod end may be attached directly to a tiebar connecting a pair of tiller arms. Ensure all measurements remain the same as if mounting to a tiller arm.*

4. Through-bolt the mounting foot to a substantial mounting structure using four 1/2" (12 mm) capscrews, washers, and self-locking nuts (use 304SS or 316SS fasteners). The cylinder is capable of exerting a force of 5500 lbf (24.5 kN), so the mounting structure must be suitable for these loads. Orient the fasteners such that if the nut were to vibrate loose the fastener would not fall out. Torque fasteners to 43 ft-lb (58 Nm).
5. Remove caps from cylinder hose fittings noting which port is labeled "U" and which port is labeled "D".
6. Before making the hose connections, swing the rudder(s) back and forth and confirm there is free movement of the cylinder and that there is no binding of the rod end or trunnion joint at the foot. Ensure SmartStick does not come close to any magnetic material or electric motors such as a bilge pump.

**⚠ WARNING**

**ANY BINDING AND OR INTERFERENCE MUST BE CORRECTED PRIOR TO USE. FAILURE TO DO SO MAY LEAD TO SEPARATION OF COMPONENTS AND/OR PREVENTION OF STEERING CONTROL, LEADING TO UNPREDICTABLE BOAT BEHAVIOR AND/OR A COLLISION WITH AN OBSTACLE AND/OR EJECTION FROM VESSEL RESULTING IN PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.**

## 5.5 Plumbing the System

### WARNING

**THE OPTIMUS EPS SYSTEM REQUIRES THE USE OF SEASTAR PRO (1500 PSI) KEVLAR REINFORCED HOSES ONLY.**

### WARNING

**DO NOT CUT SEASTAR PRO STEERING HOSE. THERE IS NO MEANS IN THE FIELD TO INSTALL A SWAGE FITTING TO THE HOSE END.**

### CAUTION

**Substituting brass fittings into the steering cylinder may result in galvanic corrosion and irreparable damage to the cylinder, as well as affect system integrity.**

### NOTICE

*Individual items (i.e. swage fitting, bulkhead plate, hose, etc.) cannot be ordered as a single part. If replacement parts are required an entire new length of hose will need to be purchased.*

Before installing the steering hoses, please read and understand the important DOs and DON'Ts below.

#### **DO:**

- ✓ Use only SeaStar Pro hose. Extruded nylon tubing is not acceptable.
- ✓ Protect the hose from chafing, rubbing, and contact with assembly screws or sharp edges of any type.
- ✓ Route hoses through a protective PVC tube if possible. If not possible, attempt to route the hoses so that they can be periodically inspected for wear or damage.
- ✓ Secure exposed sections of hoses every 12" (30cm) or less.
- ✓ Provide sufficient hose length to allow for cylinder movement throughout the turning arc.

#### **DON'T:**

- ✗ Use hoses longer than 40 ft. Runs longer than 40 feet must be plumbed with 3/8" copper or stainless steel tubing suitable for a maximum working pressure of 2000 psi.
- ✗ Install pipe sealant onto the hose side of a fitting.
- ✗ Remove the protective end caps until the hoses have been routed and are ready to be connected to the pump or cylinder.
- ✗ Install hoses in an area where they will be exposed to high temperatures. Areas to avoid are near engine manifolds and in engine compartments.
- ✗ Install hoses such that they contact electrical connections or are exposed to battery acid or fumes from batteries.
- ✗ Bend hoses tighter than a 3.5" (90mm) radius.
- ✗ Allow hoses to hang free in an area where they could become a safety hazard.

## ⚠ WARNING

**CONTINUOUS KINKING, RUBBING, CHAFING OR TWISTING OF A STEERING HOSE MAY EVENTUALLY WEAKEN THE HOSE(S) TO A POINT WHERE IT COULD RUPTURE, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND OR DEATH.**

### 5.5.1 Hose Labels

When plumbing the Optimus EPS system it is extremely important to get all of the connections in the correct place. When the hoses are being pulled through the boat it is easy to lose track of which hoses are which. To assure proper connections each kit is supplied with a sheet of labels to identify each hose end. Attach the labels to the hoses *before* routing the hoses in the boat.

Place all labels so they can be easily read after the installation is complete as they are a great help when servicing the system. See figure 5-17. Note that the labels are designed for use on a variety of vessel types, so they distinguish between Port and Starboard components; this distinction is not relevant to this system, so you may use either.




Figure 5-17.

## 5.5.2 Hose Installation

Figure 5-18 shows the general plumbing diagram for the Optimus EPS system. It is critical that the connections are made correctly, so be sure to pay attention to the port identifiers and the color coded protective caps.




Figure 5-18. Hydraulic connections.

### ⚠ CAUTION

**Do not remove the protective end caps until connections are ready to be made.**

#### Installation Procedure

1. Apply hose labels as instructed in section 5.5.1
2. Attach the hydraulic hoses to the SmartCylinder and slide the bend restrictor over the fitting as shown in figure 5-19. Torque fitting to 15 ft-lb. (20 Nm). If necessary, you can reposition the fitting on the cylinder. See section 5.5.3.
3. Route the hoses along the gunwale or inside a protective PVC pipe to the power steering pumps. Connect the hoses to the appropriate pump ports and tighten to 15 ft-lb. (20 Nm). The cylinder 'U' and 'D' ports must be connected to the corresponding pump 'U' and 'D' ports.




Figure 5-19.

### 5.5.3 Hose Fitting Reorientation (if required)

1. Back off lock nut (item 1 in figure 5-20) counter-clockwise, until it stops.
2. Thread fitting into the cylinder port until the fitting washer (item 2) contacts the face of the cylinder port. Tighten hand tight. **DO NOT USE A WRENCH.**
3. Re-position fitting to desired orientation by turning it counter-clockwise to a *maximum* of 1 full turn.
4. While holding the fitting body securely with a wrench, torque the locknut to 40–43ft-lb. Note that this torque is appropriate for the cylinder only. For fittings installed into the pump see section 5.3 for torque specification.

#### **⚠ WARNING**

**FAILURE TO PROPERLY TIGHTEN THE LOCKNUT MAY LEAD TO LOSS OF STEERING CONTROL. LOSS OF STEERING CONTROL MAY RESULT IN UNPREDICTABLE BOAT BEHAVIOR, COLLISION WITH AN OBSTACLE AND/OR EJECTION FROM VESSEL, LEADING TO PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.**

#### **NOTICE**

*Due to material variability, fitting installation torque differs between the power steering pump and the steering cylinder. Be sure to use the correct installation torque to avoid irreparable damage to the pump housing or cylinder body when installing an ORB fitting.*




Figure 5-20. Re-orientable hose fitting.




Figure 5-21.

## 5.6 Connecting the SmartCylinder

The EC5810 SmartCylinder is supplied with a stock 18 foot (5.5 m) harness. The EC5850 SmartCylinder is supplied with a stock 30 foot (9.1 m) harness. Route the harness as shown below, securing it to the hydraulic hoses every six inches (15 cm).

If additional harness length is required to reach the PCM, extension harnesses are available (see Section 4.2.5).




Figure 5-22.

### **⚠ WARNING**

**FAILURE TO SECURE HARNESS MAY RESULT IN HARNESS WEAR, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND OR DEATH.**

### **Connection at PCM**

Insert the SmartCylinder harness plugs and turn the locking rings clockwise until they click into place. The locking ring should be aligned with the marks on PCM as shown in figure 5-23.



## ⚠ CAUTION

Do not force the locking ring past the alignment marks.




Figure 5-23. PCM showing RFU connector.

## NOTICE

RFU Extension harnesses should also be strain relieved on either side of each connection.

### Proper Strain of RFU Harness

The RFU harness should be strain relieved in a manner that does not compromise the seal of the connector. The harness should extend vertically by approximately 2.5" from the base of the connector to the tallest point on the harness. Furthermore, the harness should be secured to the strain relief plate such that the primary zap strap is located between the warning and barcode labels on the harness. This configuration is shown in figure 5-24.





Figure 5-24.

*This page left intentionally blank.*

## 6.1 Network Diagrams

The following schematics illustrate the CAN1 and CAN2 network connections for various installations on large inboard vessels. (Not all possible configurations are shown.) Connections are made with simple harness connections, as shown in section 6.2.




Figure 6-1. Network diagram — single station, with autopilot.




Figure 6-2. Network diagram — dual station, with autopilot.



## 6.2 Harness Connections

### 6.2.1 Connecting the Helm and CANtrak Display

Connect the helm to the PCM using harness CM204XX (see section 4.2.1 for available lengths) as shown in figure 6-4 and figure 6-5. Use cable ties to strain-relieve the harness as shown.

Connect the CANtrak display to the helm using the harness (CM20030 or CM21504) that came with the display.




Figure 6-4.

**⚠ WARNING**


**A SEALING PLUG MUST BE INSTALLED IN ANY UNUSED PORTS.**

**⚠ WARNING**

**FAILURE TO SECURE HARNESS MAY RESULT IN HARNESS WEAR, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.**

To properly install connector, push into the socket, listen for it to click, then push the lock over, as shown below.

- TO LOCK:**
1. PRESS THE CONNECTOR FIRMLY ONTO THE RECEPTACLE
  2. LISTEN FOR THE "CLICK" AS THE CONNECTOR LOCKS
  3. PUSH TO ENGAGE THE SECONDARY LOCK



- TO UNLOCK:**
1. PUSH TO DISENGAGE THE SECONDARY LOCK
  2. SQUEEZE TO UNLATCH THE CONNECTOR
  3. PULL TO REMOVE




Figure 6-5.

Note: The CAN1 harness connection from the CANtrak to the helm may be extended using a union harness (CM22401) and an extension harness from table 4-1.

## 6.2.2 Connecting a Second Station

Figure 6-6 shows the acceptable CAN1 connections when adding a second station. If harness lengths allow (see Section 4.2.1), connect the second helm to the second CAN1 port as shown in a). This parallel configuration makes it less likely that both helms would be lost if a wiring harness is damaged.

In some cases the control station layout will require a series connection as shown in b). This is allowable provided the total harness length is within the limits shown in section 4.2.1. This configuration requires a wye harness (CM21702) in order to have enough CAN1 ports available at the main station.

If more than two helms are required then a combination of these connections will be required.




Figure 6-6. Alternate helm connections in dual-station applications.

## 6.3 Power Wiring

### WARNING

**ALL ELECTRICAL CONNECTIONS AND HARNESS MUST COMPLY WITH ABYC WIRING STANDARDS, BE RATED FOR 105° C (221° F), AND COMPLIANT WITH SAEJ1128.**

### 6.3.1 PCM Wiring

The proper wire gauge and circuit breaker rating must be used. See Section 4.3.2 for selection.

Use wire with red insulation for the positive connections and wire with black or yellow insulation for the negative connections.

1. Mount two circuit breakers, one for the port and one for the starboard power feed to each PCM within 7 inches from the power source. Use only circuit breakers designed for marine use, and with corrosion-resistant, stainless steel connection hardware.

ABYC Standards require the breakers be placed close to the batteries to protect the wires in case they are shorted. See the E-11 standard for complete details about the allowable wire length and placement of the breakers as they vary depending on how the batteries are located and protected.

### CAUTION

**Crimped and soldered connector lugs must be used on all PCM power connections.**

### CAUTION

**Do not use Automatic Power Selectors (APS) or selector diodes of any kind on the PCM power or ignition wires. This functionality is already built into the PCM.**

### WARNING

**NO ADDITIONAL DEVICES OR LOADS SHOULD BE CONNECTED TO THE PCM POWER AND GROUND POSTS. THE CIRCUIT BREAKER COULD TRIP, WHICH COULD RESULT IN LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.**

### NOTICE

*ABYC standards require that the negative terminals of all batteries on the vessel be connected together. See ABYC E-11 for more information.*

2. Run a wire from the negative terminal of the port battery to the negative terminal of the PCM port side. Run a separate wire from the negative terminal of the starboard battery to the negative terminal of the PCM starboard side.
3. Run the positive wires as shown in the diagram.
4. Tighten the PCM terminals to a maximum of 30 in-lb (3.5 Nm). Do not overtighten, as you may damage the terminals.






Figure 6-7.

\*Breakers are not supplied as part of the SeaStar Solutions Kit.

\*\* Battery Switch (PCM power may be connected directly to the battery or to the battery switch).




Figure 6-8.

### 6.3.2 PCM Wiring Strain Relief

- When all connections are made, strain relieve the wires as shown below. Be sure to properly strain relieve the wires at the power source as well.
- All unused ports must have sealing caps.




Figure 6-9.

#### ⚠ WARNING

FAILURE TO SECURE HARNESS, AS SHOWN, MAY RESULT IN HARNESS WEAR, CAUSING LOSS OF STEERING CONTROL, PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.

#### ⚠ WARNING

ALL UNUSED CONNECTORS REQUIRE SEALING PLUGS. THEY WILL LIKELY BE REQUIRED ON PCM AND THE HELM.

## 6.4 Ignition Sensing

The PCM uses an ignition-on signal from either engine to activate the steering system. Two ignition sensing leads (violet) are provided on the CM20304 harness, as shown in figure 6-8. Connect one to the port engine ignition and the other to the starboard engine ignition. A suitable ignition source is one that has system voltage when the ignition is on in either the 'Run' or 'Accessory' position.

See section 6.4.1 for important ignition splicing instructions.

### **⚠ DANGER**

**THE INTEGRITY OF THE IGNITION SENSING CIRCUIT IS CRITICAL TO THE SAFE OPERATION OF THE STEERING SYSTEM. ALWAYS CONNECT BOTH SENSING LEADS AND ENSURE THAT WIRING AND SPLICES ARE PROPERLY STRAIN- RELIEVED AND PROTECTED FROM DAMAGE, WATER, OR OTHER HAZARDS.**




Figure 6-10.

## 6.4.1 Ignition Splicing

The integrity of the ignition connection is critical to the safe operation of the Optimus EPS steering system. Please note the following:

- Whenever possible, make your splice connections in dry areas of the vessel. If you must splice in a potentially wet area, always secure the wires in a way that keeps the splice out of pooling water.
- Use sealed, heat-shrink butt splices, such as Molex Perma-Seal, or a soldered connection with heat-shrink tubing. Always follow the manufacturer's installation instructions.
- Secure the wiring on both sides of the splice so that there is no strain on the splice connection.
- Choose a route for the wires that minimizes exposure to water, high temperatures, and mechanical damage.

On most vessels you will have one of two options for an ignition source: a single ignition source wire, or you will have to splice into an existing ignition wire.

### Option 1 – single ignition source




Figure 6-11

### Option 2 – splice into an existing engine ignition wire




Figure 6-12.

## 6.5 Engine RPM Source

### 6.5.1 NMEA 2000 CAN Bus

There are two options for getting your engine speed source from an NMEA 2000 network.

Option 1 – Use existing bus: If an RPM signal is present on the NMEA 2000 bus you can connect the optional NMEA 2000 harness CM20503 to an available DeviceNet tee on the bus. If no tee is available, you will need to add one (CM10060). You may also require an extension harness to extend CM20503 to reach the tee.

Option 2 – Create new bus: You can create a basic NMEA2000 bus using kit HA5492. In addition to the kit you will need a gateway device that connects between the engine bus and the NMEA2000 bus, supplied by the engine manufacturer. Power the network from the same voltage source as the engine network.




Figure 6-13. Creating an NMEA 2000 network with kit HA5492.

#### NOTICE

When using NMEA 2000 CAN Bus for engine RPMs ensure that the black and gray analog tachometer inputs from the CM20304 CAN2 Harness are connected together.

## 6.5.2 J1939 Network Connection

There are two ways to get engine speed from a J1939 network.

Option 1 – Use existing bus: If the vessel has an available J1939 network, use the optional J1939 harness CM20034 to connect the PCM as a drop on the existing network. The harness is supplied with flying leads so that you can tie into the network at a junction box, or fit a field-installable DeviceNet connector. The CAN3 transceiver is unpowered. For this configuration to work connect to 12 or 24 volt supply and install a 1 amp fuse.




Figure 6-14. J1939 network connection.

Option 2 – Create a new bus: If there is no J1939 network on the vessel, you can create a small network and connect an engine gateway device to it, using the NMEA2000 bus kit HA5492. It will look identical to the network shown in figure 6-13, but with a J1939 gateway instead of an NMEA2000 gateway.

### NOTICE

*When using J1939 CAN Bus for engine RPMs ensure that the black and gray analog tachometer inputs from the CM20304 CAN2 Harness are connected together.*

### 6.5.3 Analog Tachometer

If you are using analog tachometers (maximum of 12 pulses per revolution) as your engine speed source, you will need to connect the gray and black tachometer leads on harness CM20304 (see figure 6-10). Connect the gray wire to the port engine analog tach input, and the black (with gray stripe) wire to the starboard analog tach input. In a single-engine application connect only the gray tachometer wire.

The leads are fitted with Molex Perma-Seal bullet connectors. The male connector is Molex P/N 191640040 and the female connector is 191640054. Crimp and seal the mating connectors (not supplied by SeaStar) onto your tachometer leads, per the manufacturer's instructions, and push together to connect.

If you are getting your input source from an NMEA 2000 network (section 6.5.1) then you need to leave the gray and black wires connected to each other as shown in figure 6-10.

## 6.6 Autopilot Connection (Optional)

Autopilots certified by SeaStar as compliant with the EPS system will simply connect to an available CAN2 network tee\*. The connection harness is supplied by the autopilot manufacturer. Refer to the manufacturer's instructions for additional information.




Figure 6-15. Autopilot connection to CAN 2 network.

**\* Important Note:** If you are using a Simrad SG05 autopilot you must use a power isolating tee such as a Navico 000-12259-001 or a Garmin 010-11580-00.

## 6.7 Buzzer Kit (Optional)

Dual or triple helm station boats do not require a CANtrak display at the second or third station. However, you must install a buzzer kit to notify the operator that the steering system has a fault and needs attention.

Locate the buzzer under the second station dash, near the helm. A warning label is included in the buzzer kit and must be applied to the dash in a visible location near the helm.

Connect the positive (yellow) and negative (pink) leads of the buzzer to the positive (yellow) and negative (pink) flying leads on the CANtrak harness at the main station.

Secure the wires adjacent to the splice for strain relief.

### Crimp connections as follows:

- Strip the wires 7.6 mm (.3") from the end and insert into the barrel of the butt splices provided (Molex 0191640043) observing the correct orientation shown below:




Figure 6-16.

- Making sure the wire end is properly seated, make the crimp connection using the recommended tool (Molex 0640014500, not included).
- Apply heat directly to the splice, working from the center out to the edges, using a hot air gun or other heat source, until the tubing shrinks and the adhesive flows.
- Allow to cool before inspecting splice and checking the integrity.

### ⚠ CAUTION

**Reversing the polarity of the buzzer may result in damage to the CANtrak harness and/or CANtrak display. 16AWG wire has been included in the kit to power the buzzer and comply with ABYC E-11. Refer to the ABYC E-11 for required gauge if longer wire runs are required.**



# 7.0 SYSTEM SETUP AND CONFIGURATION

## 7.1 First-Time Power-up of the System

---

The first few times you turn on your system you will get a number of warnings and alarms. These warnings exist because the system has not yet been fully configured and calibrated. Silence the buzzer by pressing Mute on the display.

In some cases the active alarms will hide the Menu button, but it is always the right-most button under the display. Press and hold this button for five seconds to get access to the Dealer Menu PIN entry screen. **See SeaStar book 65 section 2.1.4 for more information.**

## 7.2 Initial Setup

---

Initial Setup is performed from the System Setup screen. Navigate to **Dealer Menu > Initial Setup > System** and you will see the setup steps presented in order on the display. It is important to perform these steps in the order shown.

If you are unfamiliar with CANtrak display navigation, review SeaStar book 65 section 2.1.




Figure 7-1.

Navigate through the menu's to select the Optimus EPS system type  
**Initial Setup > System > Select System Type.**




Figure 7-2.

The next step is to tell the system what type of steering cylinders are installed: Navigate through the menu and select either the EC5810 or EC5850 **Initial Setup > System > Select Steering Type >.**




Figure 7-3.

Navigate through the menu's and set the system number of devices  
**Initial Setup > System > Select Number of Devices.**

### **7.2.1 Select Number of Devices**

The CANtrak will display a list of devices based on the system type. Use the + and – buttons to change the quantity of each device to match the system.

These parameters tell the system how many of each device to look for on the CAN network. If the numbers do not match you will get repeated error messages from the display.

### **7.2.2 Select Device Locations**

This step is only required when there are multiple helm stations in the system.

The CANtrak will list all of the devices on the CAN network along with their serial numbers. Match the devices by the serial numbers and use the + and – buttons to toggle the components between Main and 2nd (or 3rd in supported systems) station.

### **7.2.3 Select RPM Source**

Choose the engine RPM source from the list of RPM sources. Only sources that are valid for the selected system type will be displayed.

If you select an analog tachometer as the RPM source you will also need to enter the PPR value of the tachometer.

## 7.3 Steering Setup

All the steering setup tasks are done from the Steering Setup menu at **Dealer Menu > Initial Setup > Steering**.

**For Datalink users:** All steering system setup parameters are found on the Configuration tab of the PCM interface.




Figure 7-4.

## 7.4 Configuration (Inboard Only)

If you selected an inboard cylinder type during the **Initial Setup > System** step, you will see this additional setup step.

### NOTICE




Figure 7-5.

### NOTICE

*It is important to complete this setup step before continuing to the purge and calibrate steps. Do not mix up the order of these steps. This applies to inboard systems only.*

### **Step 1 – Set Extended Cylinder Turn Dir.**

This parameter tells the system which direction the boat steers when the steering cylinder is *extended*. The default value is N/A. Change the parameter so that it correctly reflects how the cylinder is installed. There are parameters for both port and starboard cylinders; in a single cylinder installation there is only one parameter to set.

You must set this parameter or the CANtrak will display a Danger fault after calibration and you will not be able to steer the boat.

### **Step 2 – Set System Voltage**

The 5000 series twin cylinder system is designed to work with a 24V power supply. Ensure the system voltage is set to 24V.

### **Step 3 – Set Cylinder Tie-bar Option (Twin EC581X Only)**

This parameter tells the system that the two steering cylinders are connected by a physical tie-bar.

### **Step 4 – Set Hard Stop Rudder Angle**

The angle the rudder steers through depends on the tiller arm length, as tabulated in the installation instructions for the inboard cylinder. The Hard Stop Rudder Angle parameter tells the system the actual rudder angle at hard over, and is used to calibrate the rudder angle display on the system run screen. Changing the parameter will not change the actual steering angle of the vessel — that is handled by the Rudder Limit parameters in section 7.9.4. It will however change the number displayed on the screen.

*Note:* the rudder angle is one-half the total steering angle tabulated in the installation instruction. For example, a steering angle of 70° corresponds to a rudder angle of 35° in each direction.

Select the Hard Stop Rudder Angle parameter and use the + and – buttons to adjust it as required.

## 7.5 Purge the Steering System

**For Datalink users:** Purge commands are found on the Configuration tab of the PCM interface.

With its electronic helm and simple hydraulic circuit it is much easier to purge the air from an Optimus EPS system than traditional hydraulic steering systems. You will require the following:

- Optimus EPS Steering Fluid, HA5482. Your core component kit includes enough fluid for a typical installation.
- A purge hose kit. Available in two lengths:
  - 15 ft (4.5 m): HA5486
  - 30 ft (9 m): HA5487
- A 1/2" (13 mm) open end wrench.

### General Notes:

- You can only purge one cylinder/pump pair at a time.
- Before purging, open the service valve on the pump and manually move the engine (or outdrive/rudder) through the full range of the cylinder stroke and check for interference at the end of stroke. If there is any interference you will need to either address it before purge/calibrate, or purge and calibrate with the cylinder disconnected from the tiller. To prevent damage you will need to decrease the Low Speed Rudder Limit (section 7.9.4) before connecting the steering cylinder.

### NOTICE

*For inboard cylinders that are connected with a tie-bar, the tie-bar must be connected AFTER purging is complete.*

### Procedure:

1. Remove the black caps from the bleed fittings on the SmartCylinder and its corresponding power steering pump. Take care not to lose them.
2. Connect the purge hose as shown in figure 7-6.
3. Open all three bleed fittings 1-1/2 to 2 turns.

### ⚠ CAUTION

**Failure to open the pump bleed fitting (item 3 in figure 7-6) may cause the purge hose to rupture.**




Figure 7-6.

4. Fill the reservoir on the power steering pump to the MAX level on single motor pumps and to the top of the sight glass on dual motor pumps (used on large inboard systems). Do not overfill, as air coming back during the purge may cause the fluid to overflow.
5. Double check that the purge hose is connected to the correct pump and cylinder and that the bleed fittings are opened. The purge hose may be damaged otherwise.
6. Turn the ignition on and power up the Optimus system.

**⚠ CAUTION**

**DO NOT turn the helm at this time or the hydraulic pump will run. Should this accidentally occur power off the system for 3 seconds then power back on. This will stop the pump.**

7. Navigate to Dealer **Menu > Initial Setup > Steering > Purge Cylinders** to access the Purge Cylinders menu.




Figure 7-7.

8. Select the cylinder to purge and press ► to enter Purge Mode. If you don't see the Purge Cylinder screen as shown in figure 7-8, cycle the system power and try again. The system will not enter Purge Mode if the helm has been turned since the ignition was turned on.




Figure 7-8.

## NOTICE

When purging you will be required to turn the helm AND maintain fluid level in the pump reservoir. The pump can empty the reservoir quickly while purging. When the fluid level in the reservoir drops to the MIN mark, stop turning the steering wheel and refill the reservoir to the MAX mark (or to the top of the sight glass). DO NOT ALLOW THE FLUID LEVEL TO GO BELOW THE MIN MARK.



9. Turn the helm one direction to start the purging process. The pump will run as the wheel is being turned. Continue turning the wheel until the cylinder reaches the end of travel. Verify the pump oil level frequently.
10. Turn the wheel in the opposite direction until the cylinder reaches the end of travel. Verify the pump oil level frequently.
11. Repeat steps 9 & 10 until no more air bubbles appear in the purge hose. Verify pump oil level frequently
12. Close both cylinder bleeders. DO NOT close the pump bleeder yet.
13. Open the service valve for the tiller/rudder being purged and move the tiller/rudder by hand so that the cylinder moves about 3 inches.
14. Close the service valve.
15. Re-open the cylinder bleeders 1½ to 2 turns.
16. Repeat steps 9 & 10 until no more air bubbles appear in the purge hose. Verify pump oil level frequently.
17. Close all three bleed fittings, remove the purge hose and replace the bleeder protective caps.
18. Press **J** to return to the Purge Cylinders menu. If this is a single tiller/rudder application skip to step 21.
19. Move the purge hose to the next cylinder and pump to be purged.
20. Repeat steps 7 to 18 for the other cylinder.
21. If you need to calibrate the SmartCylinders, proceed to section 7.6 now. Otherwise, press **J** repeatedly to exit. You will be prompted to perform a key cycle in order to exit the steering setup.

**TIP:** When purging is complete the cylinder should have 3/8" or less of movement when physically trying to shake the tiller/rudder back and forth.

## 7.6 Calibrate the SmartCylinders

### **⚠ WARNING**

**DURING THE CALIBRATION PROCEDURE THE TILLER/RUDDER WILL MOVE THE FULL TRAVEL OF THE STEERING RANGE. CONFIRM THERE ARE NO OBSTRUCTIONS IN THE PATH OF THE TILLER/RUDDER. IF THERE IS AN OBSTRUCTION REQUIRING STROKE REDUCTION, THE CYLINDER MUST FIRST BE CALIBRATED WITH THE SUPPORT BRACKETS REMOVED.**

### **⚠ CAUTION**

**The Optimus EPS system must be fully purged of air before calibration is attempted. Any air in the system will prohibit calibration and will cause the system to exhibit faults.**

### **NOTICE**

*For inboard cylinders that are connected with a tie-bar, the tie-bar must be connected BEFORE calibrating the cylinders.*

1. If this is a multi-engine outboard or sterndrive, move the starboard engine as far outboard as possible by opening the service valve and moving it by hand. Close the service valve. This will prevent collision when the port engine moves during calibration.
2. On the display, navigate to **Dealer Menu > Initial Setup > Steering > Calibrate Cylinders** to access the Calibrate Cylinders menu.

**For Datalink users:**

Calibration commands are found on the Configuration tab of the PCM interface.




Figure 7-9.

3. Select **Calibrate Port Cylinder** and press > to enter **Calibration Mode**.




Figure 7-10.

4. Turn the helm to starboard until the status indicator reports hardstop is reached. Next, turn the helm to port until hardstop is reported. When finished, the port engine or outdrive should be turned all the way outboard

5. When cylinder calibration is completed you will be returned to the Calibrate Cylinders menu. If this is a single cylinder application skip to step 7.
6. Repeat step 4 for the starboard cylinder.
7. When all cylinders are calibrated press **J** repeatedly to exit. You will be prompted to perform a key cycle in order to save the calibration and exit the steering setup.
8. Power up the system and turn the helm. The engines/outdrives/rudders should align automatically, and the steering should operate normally. If the display reports a calibration error you will need to re-calibrate the indicated cylinder.

## 7.7 Align Rudders (Inboard & Sterndrive Only)

On inboard and sterndrive vessels it is possible that the rudders/outdrives may not be aligned straight ahead when the steering cylinder is at its calculated zero position. On a twin sterndrive this can also result in outdrives that are not parallel.

You can correct these issues in **Steering Setup > Align Rudders**.




Figure 7-11. Align Rudders appears when an inboard or sterndrive cylinder type is selected.

### **⚠ CAUTION**

**The Align Rudders menu contains items that will cause the steering gear to move. Ensure that no one is near the moving parts of the steering gear, including outdrive(s), steering cylinder(s), rudders and/or tiller(s).**

### **Step 1 – Enable Rudder Alignment**

On the Align Rudders screen you must first enable rudder alignment. Use the + or – button to toggle the parameter from No to Yes. Additional menu options will be displayed as shown in figure 7-12. (The Parallel Rudder Correction parameter is only visible on systems with two steering cylinders.)

When Enable Rudder Alignment is toggled to Yes on a twin cylinder system the steering range of the cylinders is adjusted so that they are both the same. One of the cylinders may move a small amount.




Figure 7-12. Align Rudders screen for twin sterndrive system.

### Step 2 – Parallel Rudder Correction

Select Parallel Rudder Correction and press **Toe-in** or **Toe-out** to adjust the rudders or outdrives until they are parallel. For best results use a tape measure to check that they are parallel. Only the starboard drive/rudder will move.




Figure 7-13. Parallel Rudder Correction.

### Step 3 – Straight Line Correction

Steer with the helm until the rudder(s) or outdrive(s) are aligned straight ahead. The Rudder value on the display will show the amount of correction that will be applied. Press **Set** on the display to apply the correction; you will see the Straight Line Correction value update and the Rudder value will go to 0.0. The display will now show 0° rudder when the drive(s) is straight ahead.




Figure 7-14. Straight Line Correction.

In some cases the vessel will not track straight through the water when the rudder/drive is aligned straight ahead. This can be corrected by performing this step again during sea trial. Steer the helm until the vessel is tracking straight at cruising speed, then press **Set**.

#### Clear Rudder Corrections

You can clear all rudder corrections and revert to the original calibration state using this menu item.

## 7.8 Set Proportional Sensitivity

Proportional rudder sensitivity can be used to increase the helm sensitivity at the neutral rudder position for more responsive steering. The total number of helm turns lock-to-lock is unchanged, so the steering becomes less sensitive as you approach hard over. Proportional Sensitivity is set in **Steering Setup > Set Proportional Sensitivity**. There are two parameters:

**Proportional Sensitivity Gain:** This parameter controls the increase in sensitivity. The range is from 0.5 to 4.0, and represents a multiplier of the standard helm sensitivity. The default value of 1.0 means there is no change, and a value of 4.0 means the helm sensitivity is four times the normal setting. The multiplier applies at zero steering angle, then decreases linearly as steering angle increases. We suggest that you start with a gain of no more than 2 and sea trial before increasing the gain.

**Proportional Sensitivity Range:** This is the steering angle range (from zero degrees) over which the Sensitivity Gain is applied. The range is from zero degrees to the Hardstop Rudder Angle that you set in section 7.4.

## 7.9 Steering Parameters

### 7.9.1 Speed Sensitive Steering

A key advantage of Optimus electronic power steering is the ability to change steering parameters as boat speed changes. The steering feel and response can be tailored to user preference, and to keep vessel operation within a comfortable performance envelope.

The speed-dependent parameters are smoothly varied between low and high-speed settings as boat speed changes. Figure 7-15 illustrates how this works.




Figure 7-15.

### 7.9.2 Low and High Speed Thresholds

Optimus EPS uses engine RPM to determine boat speed\*. There are low and high speed threshold values that you can set. The default values (see table 7-1) will be suitable for many gasoline outboard engines, but they will be too high for diesels and some large displacement, low-revving gasoline inboards.

**Low Speed Engine RPM:** This is the engine speed below which the low speed settings are in effect. For planing hulls you typically want to use the engine RPM at which the boat begins to get up on plane. For displacement and semi-displacement hulls you might consider using engine RPM corresponding to typical marina speed limits. The valid RPM range is shown in table 7-1.

**High Speed Engine RPM:** This is the engine speed above which the high speed settings are in effect. This will typically be close to maximum RPM, and must be set at least 500 higher than the Low Speed Engine RPM. The valid RPM range is shown in table 7-1.

\* In some cases the throttle command percentage may be used, but this is not recommended. Consult with SeaStar.

### 7.9.3 Steering Parameter List

**For Datalink users:** these parameters are available in the Configuration tab of the PCM interface.

Table 7-1 lists the steering parameters available in the system. User parameters are marked with a (U) and can be adjusted by the vessel operator provided access is given to the Settings menu (See section 7.9.5). The shaded parameters are speed-dependent. Steering parameters are adjusted from the CANtrak display at **Dealer Menu > Settings > Steering > Steering Settings**.

SUBMENU	PARAMETER NAME	DESCRIPTION	RANGE	DEFAULT VALUE
	Low Speed Toe Angle	Sets the toe angle of the engines (or outdrives/rudders) when the vessel is running at low speed. A positive value will toe the engines out (gear cases farther apart at front edge).	-1.5 to 1.5	0
	High Speed Toe Angle	Sets the toe angle of the engines (or outdrives/rudders) when the vessel is running at high speed. A positive value will toe the engines out (gear cases farther apart at front edge).	-1.5 to 1.5	0
	Inner/Outer Steering Ratio	This parameter can make the inner engine (or outdrive/rudder) turn more than the outer engine in a turn. The higher the value the less the outer engine will turn. E.g. A value of 2.0 will deliver 15 degrees of steering at the outer engine when the inner engine is steered at 30 degrees.	1 to 3	1
Speed Signal	Speed Signal	Sets how the boat speed is determined. Except in rare cases you should leave this as the default value.		Engine RPM
	Low Speed Engine RPM	Sets the engine RPM that marks the upper boundary of low speed. This is typically the RPM at which the boat begins to plane. See figure 7-15.	0 to 2500	1500
	High Speed Engine RPM	Sets the engine RPM that marks the lower boundary of high speed. Typically close to maximum RPM. See figure 7-15.	500 to 6000	4000
	Low Speed Throttle Cmd	Sets the throttle percentage that marks the upper boundary of low speed. Used when Speed Signal is set to Throttle Cmd.	0 to 35	30
	High Speed Throttle Cmd	Sets the throttle percentage that marks the lower boundary of high speed. Used when Speed Signal is set to Throttle Cmd.	45 to 100	60
Helm Effort	Helm Effort at Low Speed (U)	Sets the helm effort when the vessel is running at low speed. The value is a percentage of maximum effort (steering locked).	1 to 100	40
	Helm Effort at High Speed (U)	Sets the helm effort when the vessel is running at high speed.	1 to 100	60
	Helm Effort in Autopilot (U)	Sets the helm effort when the vessel is running in autopilot. Set it high enough to prevent accidental movement of the helm.	20 to 100	90
	Helm Effort in Joystick Mode	Sets the helm effort when the vessel is running in joystick mode.	20 to 100	90
Helm Turns and Rudder Limits	Helm Turns at Low Speed (U)	Sets the number of turns when the vessel is running at low speed.	3.5 to 8.5	5
	Helm Turns at High Speed (Full Stroke) (U)	Sets the number of turns for full stroke of the steering cylinder(s) when the vessel is running at high speed.	3.5 to 8.5	5
	Low Speed Rudder Limit (Formerly Max Steering Angle)	This parameter is most often used to restrict the travel of outboard engines in installations where there is interference at high steering angles.	15 to 'Hardstop Rudder Angle' (See 7.4)	30
	High Speed Rudder Limit	This parameter can be used to limit the maximum steering angle when the vessel is at high speed. It can restrict the operator from overly aggressive and potentially unsafe maneuvers.	10 to 'Low Speed Rudder Limit'	30
	Joystick Mode Rudder Limit (Formerly Max Joystick Angle)	This parameter applies only to Optimus 360 systems. It is used to limit the maximum steering angle in joystick mode in the event there is some interference.	0 to 30	30

Table 7-1. Steering Settings.

## 7.9.4 Set Rudder Limits

### ⚠ WARNING

**THE OPTIMUS EPS SYSTEM MUST BE FULLY PURGED OF AIR AND THE SMARTCYLINDER MUST BE CALIBRATED BEFORE THE STEERING ANGLE IS ADJUSTED.**

### ⚠ WARNING

**CHANGING PCM PARAMETERS MAY CAUSE THE TILLER/RUDDER TO MOVE AUTOMATICALLY AS SOON AS THE PARAMETERS ARE ENTERED.**

Rudder Limits are optional parameters that can be used to restrict the steering angle of the system. These parameters are set from **Dealer Menu > Settings > Steering > Helm Turns and Rudder Limits**. The default values are 30° for outboard and sterndrive systems, and the Hardstop Rudder Angle (section 7.4) for inboard systems.




Figure 7-16.

There are three Rudder Limit parameters:

**Low Speed Rudder Limit:** This parameter is generally used to restrict the steering angle of outboard engines when there is interference between engines or other restrictions in the splashwell, but it can also be used on inboard and sterndrive systems if it is useful to restrict the steering angle. Despite the name, this parameter limits the maximum steering angle at all speeds, because the High Speed Rudder Limit cannot be set higher.

**High Speed Rudder Limit:** This parameter can be used to restrict the maximum steering angle when the vessel is operated at high speed. It can help prevent aggressive maneuvers, limit steering loads, or prevent cavitation. The rudder limit is adjusted smoothly as speed increases so there is no step change in steering angle.



## 7.9.5 User Permissions

User access to user parameters is not enabled by default. To enable them, navigate to **Dealer Menu > Settings > Display > Settings Menu Access** and press **+** to toggle the setting.

**For Datalink users:** this parameter is available in the Configuration tab of the Color Display interface.




Figure 7-17.

## 7.10 Generic Setup Twin Cylinder Inboard

Setting up the vessel personality through color display and dealer menu selection for EPSK1500 & EPSK1280 twin cylinder systems.

### 7.10.1 Devices Menu Settings

DEVICES MENU Options Available	MENU PICK	VALUE INPUT	VARIABLE DEFINITION
DEVICES> MAIN COLOR DISPLAY> CONFIGURATION>DISPLAY	Display Rudderbar	ON/OFF	<b>Definition:</b> When set to ON. The color display will show only the rudder position bar with no RPM displayed. <b>Definition:</b> When set to OFF. The color display will show two decimal rudder position angle with single decimal RPM. If you are only using one engine RPM input it will only show one RPM.

Table 7-2. Devices Menu Settings.

### 7.10.2 Initial Set Up Menu Settings

INITIAL SET UP MENU Options Available	MENU PICK	VALUE INPUT	VARIABLE DEFINITION
INITIAL SET UP>SYSTEM> SELECT SYSTEM TYPE>	Optimus EPS	Yes	<b>Definition:</b> For inboard vessels this is the only steering option, Joystick maneuvering is not available by SeaStar.
INITIAL SET UP>SYSTEM> SELECT STEERING TYPE>	Inboard EC581X		<b>Definition:</b> Large 2-1/8 inch Dia. cylinder 9.25 inch stroke.
	Inboard EC585X		<b>Definition:</b> Large 2-1/8 inch Dia. cylinder 12 inch stroke.
	Number of Helms		
INITIAL SET UP>SYSTEM> SELECT NUMBER OF DEVICES	Number of Cylinders		
	Number of Displays		

Table 7-3. Initial Set Up Menu Settings.

## Initial Set Up Menu Settings – Continued

<b>INITIAL SET UP&gt;SYSTEM SELECT&gt;DEVICE LOCATIONS</b>	Main Helm	Serial Number	<b>Definition:</b> Identify which helm is at the main station by looking at the serial number on the back of the unit. Use DEVICE>MAIN HELM>PRODUCT INFORMATION look for the serial number reported by that device.
	Second Helm	Serial Number	<b>Definition:</b> Identify which helm is at the second station by looking at the serial number on the back of the unit. Use DEVICE>SECOND HELM>PRODUCT INFORMATION look for the serial number reported by that device.
	Main PCM	Default	
	Main Display	Serial Number	<b>Definition:</b> Identify which display is at the main station by looking at the serial number on the back of the unit. Use DEVICE>MAIN DISPLAY>PRODUCT INFORMATION look for the serial number reported by that device.
	Second Display	Serial Number	<b>Definition:</b> Identify which display is at the second station by looking at the serial number on the back of the unit. Use DEVICE>SECOND DISPLAY>PRODUCT INFORMATION look for the serial number reported by that device.
<b>INITIAL SET UP&gt;SYSTEM&gt; SELECT RPM SOURCE</b>	J1939		<b>Definition:</b> On setting source to J1939 it is normal that only 1 RPM will be taken by the Optimus system. In many cases the engines are not instances '0' port & '1' stbd.
	NMEA2000		<b>Definition:</b> Setting source to NMEA2000 it is highly likely that both RPM's will be broadcast on the vessel network as their correct instance.
	PCM Tach		<b>Definition:</b> Setting source to PCM Tach will take an analog pulse input as RPM. Use the Black and Grey wires on CAN2 port at the PCM. Settings available 1 pulses per rev through 12 pulses per rev. (PPR).
<b>INITIAL SET UP&gt; STEERING&gt;SET PROPORTIONAL SENSITIVITY</b>	Angle proportional Gain	0	<b>Definition:</b> Gain is a steering wheel speed multiplication factor. Rotate the wheel at one revolution per second with gain set to 4 the effect will be turning the wheel 4 times faster per second. Default is zero.
	Rudder Gain Angle	0	<b>Definition:</b> The faster speed of steering input can be applied to a specific range of rudder angle. Typically the first $\pm 2$ or $\pm 3$ degrees of rudder movement has limited effect on the vessel initiating a turn. The Optimus system will move through this $\pm 3$ dead zone more rapidly giving a more responsive feel at the helm. The value input is a $\pm$ value if it is set to 5 degrees then the rudders will have a speed increase applied to a total of 10 degrees of rudder angle. Default is zero.
<b>INITIAL SET UP&gt; STEERING&gt;CONFIGURATION</b>	Battery Type	12/24 Volt	<b>Definition:</b> Default is 24 volt.
<b>INITIAL SET UP&gt; STEERING&gt;CONFIGURATION CYLINDER-SET EXTENDED CYLINDER TURN DIR.</b>	Port Extended Cylinder Turn Direction		<b>Definition:</b> Dependent on the mounting configuration of the cylinders as to which way will the vessel turn if the cylinder extends.
	Starboard Extended Cylinder Turn Direction		<b>Definition:</b> Dependent on the mounting configuration of the cylinders as to which way will the vessel turn if the cylinder extends.
<b>INITIAL SET UP&gt; STEERING&gt;ALIGN RUDDERS&gt;</b>	Enable Rudder Alignment	Yes/No	<b>Definition:</b> If this menu option is switched to No the below two options below will not appear. Default is No.
	Parallel Rudder Correction	0	<b>Definition:</b> Discrepancies in the manufacture of any vessel may cause the rudders to be slightly out of parallel. Using the correction variable, +1 or -1 degree increments will add or subtract angle to a single rudder. Adjust until both the leading edges and trailing edges of the rudders measure the same distance apart.
	Straight Line Correction	0	<b>Definition:</b> Discrepancies in the manufacture of the vessel may cause it to track slightly to port or starboard when steering straight. This can be zeroed out during sea trial. Best results are done at cruising speed.
<b>INITIAL SET UP&gt; STEERING</b>	Hard Stop Rudder Angle		<b>Definition:</b> The angle the rudder steers through depends on the tiller arm length, as tabulated in the installation instructions for mounting the inboard cylinder. The Hard Stop Rudder Angle parameter tells the system the actual rudder angle at hard over. It is also used by the display on the system run screen at the end of the rudder slider graphic. If the value is set to 35 then the display will show at each end of the ruder bar the number 35 this represents a total of 70 degrees lock to lock.

Table 7-3 – Continued. Initial Set Up Menu Settings.

## 7.10.3 Settings Menu Settings

SETTINGS MENU Options Available	MENU PICK	VALUE INPUT	VARIABLE DEFINITION
SETTINGS>STEERING>TOE ANGLE	Toe Angle Low Speed	0	<b>Definition:</b> Toe out + Ve this where the trailing edges of the rudder move further apart. Toe in - Ve this where the trailing edges of the rudder move closer together.
	Toe Angle High Speed	0	<b>Definition:</b> Toe out + Ve this where the trailing edges of the rudder move further apart. Toe in - Ve this where the trailing edges of the rudder move closer together.
SETTINGS>STEERING	Inner & Outer Rudder Ratio		<b>Definition:</b> This is similar to Ackerman found in steering of motor cars. The outer rudder in a turn will move to a lesser angle. Scribing a larger diameter circle than the inner rudder. The distance between the rudders effects the chosen ratio. Typical ratio values: 5-10 feet between rudders & 30 degree max. rudder angle, set ratio to 1.1. 10-14 feet between rudders & 30 degree max. rudder angle, set ratio to 1.2. 14-18 feet between rudders & 30 degree max. rudder angle, set ratio to 1.3. 18-23 feet between rudders & 30 degree max. rudder angle, set ratio to 1.4.
SETTINGS>STEERING>SPEED SIGNAL	Speed Signal Source	Engine RPM	<b>Definition:</b> Set to Engine RPM, this is how the Optimus system assess the speed of the vessel.
	Low Speed Engine RPM	1200	<b>Definition:</b> The helm feel or resistance, the number of turns lock to lock and the toe in or out values all change with speed (RPM's) The RPM value chosen here acts as the beginning point of the transition to high speed settings. Typical low speed values would be 1000 RPM. All vessel operations below 1000 RPM will be conducted at the low speed settings.
	Hi Speed Engine RPM	1800	<b>Definition:</b> The helm feel or resistance, the number of turns lock to lock and the toe in or out values all change with speed (RPM's) The RPM value chosen here acts as the ending point of the transition to high speed settings. Typical hi speed values would be 100 RPM below cruising speed E.g. if cruising RPM is 1800 then select 1700 RPM. All vessel operations at 1700 RPM and above will be conducted at the hi speed settings.
SETTINGS>STEERING>HELM EFFORT	Helm Effort at Low Speed	30	<b>Definition:</b> Within the EPS electronic helm is an electromagnetic clutch, more voltage more magnetic field, gives more resistance feeling in the steering wheel. Typical settings is a nice fingertip steering, bigger wheel diameter will require higher % values. Preferably the wheel should not free spin.
	Helm Effort at High Speed	45	<b>Definition:</b> Within the EPS electronic helm is an electromagnetic clutch, more voltage more magnetic field, gives more resistance feeling in the steering wheel. Typical settings is a nice firm steering, preferably the wheel should not jog when pushing through rough seas. Bigger wheel diameter will require higher % values.
	Helm Effort Autopilot	90	<b>Definition:</b> Default value is 90%, the helm if touched will disengage the autopilot. This setting holds the helm such that accidental wheel bumping will not disengage AP. In case of emergence object avoidance the wheel can be easily turned.
SETTINGS>STEERING>HELM TURNS & RUDDER LIMITS	Helm Turns Low Speed	3.5	<b>Definition:</b> At the previously set low RPM values the number of turns lock to lock at that RPM can be set.
	Helm Turns High Speed	5	<b>Definition:</b> At the previously set high RPM values the number of turns lock to lock can be set.
SETTINGS>STEERING>HELM TURNS & RUDDER LIMITS	Low Speed Rudder limit	35	SeaStar Solutions will calculate rudder torque, loads and hydraulic pressures from the data previously supplied in the vessel survey form. It is extremely important to follow the recommendations given. <b>Definition:</b> The maximum rudder angel possible has been set during the mounting of the hydraulic cylinder and attachment point of cylinder trunnion to tiller arm. If the cylinder is mounted for $\pm 35$ degrees then the low speed setting for rudder limits should be 35 degrees. However it could be set to less with if the user demands.
	High Speed Rudder Limits	25	SeaStar Solutions will calculate rudder torque, loads and hydraulic pressures from the data previously supplied in the vessel survey form. It is extremely important to follow the recommendations given. The three factors that most profoundly affect rudder load are: <ul style="list-style-type: none"> <li>• Speed of the vessel through the water</li> <li>• Area of rudder ahead of the rudder post verses behind (counterbalance)</li> <li>• Rudder angle (higher angle higher load)</li> </ul> <b>Definition:</b> The maximum rudder angel possible has been set during the mounting of the hydraulic cylinder and attachment point of cylinder trunnion to tiller arm. The high speed rudder limit must be set to SeaStar recommendations.

Table 7-4. Settings Menu Settings.

*This page left intentionally blank.*

# APPENDIX A MOUNTING TEMPLATES

## A.1 Helm Templates

### A.1.1 Front Mount Helm (EH1510/EH1512)

#### NOTICE

*If this template has been downloaded electronically or copied from another document, please verify all template dimensions prior to cutting. Print/copy reproductions may be scaled differently.*




Figure A-1.

*This page left intentionally blank.*

## A.1.2 Sport Plus Tilt Helm (EH1530/EH1532)

### NOTICE

*If this template has been downloaded electronically or copied from another document, please verify all template dimensions prior to cutting. Print/copy reproductions may be scaled differently.*




Figure A-2.

*This page left intentionally blank.*



### A.1.3 Classic Tilt Helm (EH1550/EH1552)

#### NOTICE

*If this template has been downloaded electronically or copied from another document, please verify all template dimensions prior to cutting. Print/copy reproductions may be scaled differently.*




Figure A-3.

*This page left intentionally blank.*

### A.1.4 Rear Mount Helm (EH1570/EH1572)

#### NOTICE

*If this template has been downloaded electronically or copied from another document, please verify all template dimensions prior to cutting. Print/copy reproductions may be scaled differently.*

#### CAUTION

**This template to be used for EH1570 and EH1572 ONLY. See figure A-5 on page A-8 for EH1592 template.**




Figure A-4.

## Rear Mount Helm (EH1592) 1" Straight Shaft

### NOTICE

*If this template has been downloaded electronically or copied from another document, please verify all template dimensions prior to cutting. Print/copy reproductions may be scaled differently.*

### ⚠ CAUTION

**This template to be used for EH1592 ONLY. See figure A-4 on page A-7 for EH1570 and EH1572 template.**

### ⚠ WARNING

**MINIMUM DASH THICKNESS TO BE ONE INCH. CONTACT SEASTAR SOLUTIONS FOR INSTRUCTION ON HOW TO MOUNT TO NON-STANDARD DASHES.**




Figure A-5.

## A.2 CANtrak Display

### NOTICE

*If this template has been downloaded electronically or copied from another document, please verify all template dimensions prior to cutting. Print/copy reproductions may be scaled differently.*




Figure A-6. Color CANtrak Display Mounting Template.

*This page left intentionally blank.*

## A.3 PCM Mounting Dimensions




Figure A-7.

## A.4 Power Steering Pump Mounting Dimensions

### NOTICE

*On early production tanks the center-to-center dimension is 3.1" (78mm). Check the tank to confirm the measurement before drilling.*





Figure A-8.



# APPENDIX B BOLT TORQUE SPECIFICATIONS

These are the recommended maximum torque values for reusable dry bolts. Bolts should be torqued to this value +0% - 20%. For lubricated bolts, multiply the dry bolt torque values by 0.75.

Values are stated in: ft/lbs (N.m)								
Bolt Size	18-8SS	Brass	Bolt Size	18-8SS	Brass	Bolt Size	18-8SS	Brass
2-56	2.5 (.282)	2.0 (.226)	6-32	9.6 (1.08)	4.9 (.554)	5/16"-18	132.0 (14.91)	107.0 (12.10)
2-64	3.0 (.338)	2.5 (.282)	6-40	12.0 (1.35)	9.9 (1.12)	5/16"-24	142.0 (16.04)	116.0 (13.11)
3-48	3.9 (.440)	3.2 (.361)	8-32	20.0 (2.25)	16.0 (1.81)	3/8"-16	236.0 (26.66)	192.0 (21.71)
3-56	4.4 (.497)	3.6 (.407)	8-36	22.0 (2.48)	18.0 (2.03)	3/8"-24	259.0 (29.20)	212.0 (23.97)
4-40	5.2 (.587)	4.3 (.486)	10-24	23.0 (2.59)	19.0 (2.14)			
4-48	6.6 (.740)	5.4 (.610)	10-32	32.0 (3.61)	26.0 (2.94)			
5-40	7.7 (.869)	6.3 (.712)	1/4"-20	75.0 (8.47)	62.0 (7.01)			
5-44	9.4 (1.06)	7.7 (.869)	1/4"-28	94.0 (10.6)	77.0 (8.70)			
Values are stated in: ft/lbs (N.m)								
Bolt Size	18-8SS	Brass	Bolt Size	18-8SS	Brass	Bolt Size	18-8SS	Brass
7/16"-14	31.0 (42.00)	26.0 (35.25)	5/8"-11	93.0 (126.09)	76.0 (103.04)	1"-8	287.0 (389.12)	235.0 (318.62)
7/16"-20	33.0 (44.74)	27.0 (36.61)	5/8"-18	104.0 (141.00)	85.0 (115.24)	1"-14	259.0 (351.16)	212.0 (287.43)
1/2"-13	43.0 (58.30)	35.0 (47.45)	3/4"-10	128.0 (173.55)	104.0 (141.00)			
1/2"-20	45.0 (61.01)	37.0 (50.17)	3/4"-16	124.0 (168.12)	102.0 (138.29)			
9/16"-12	57.0 (77.28)	47.0 (63.72)	7/8"-9	194.0 (236.03)	159.0 (215.58)			
9/16"-18	63.0 (85.42)	51.0 (69.15)	7/8"-14	193.0 (261.67)	158.0 (214.22)			

Table B-1.

[illegible]

# WARRANTY

## Statement of Limited Warranty

We warrant to the original retail purchaser that **Marine Canada Acquisition Inc. DBA SEASTAR SOLUTIONS** (herein forward referred to as SeaStar Solutions) products have been manufactured free from defects in materials and workmanship. This warranty is effective for two years from date of purchase, excepting that where **SeaStar Solutions** products are used commercially or in any rental or income producing activity, then this warranty is limited to one year from the date of purchase.

We will provide replacement product without charge, for any **SeaStar Solutions** product meeting this warranty, which is returned (freight prepaid) within the warranty period to the dealer from whom such product were purchased, or to us at the appropriate address. In such a case **SeaStar Solutions** products found to be defective and covered by this warranty, will be replaced at **SeaStar Solutions'** option, and returned to the customer.

The above quoted statement is an extract from the complete **SeaStar Solutions** products warranty statement. A complete warranty policy is available in our **SeaStar Solutions** products catalogue.

*For more information please visit our website:*

**[www.seastarsolutions.com/support-2/warranty-2/seastar-solutions-warranty](http://www.seastarsolutions.com/support-2/warranty-2/seastar-solutions-warranty)**

## Return Goods Procedure

Prior to returning product to **SeaStar Solutions** under warranty, please call: **604-248-3858** or email: **[Marine.Warranty@seastarsolutions.com](mailto:Marine.Warranty@seastarsolutions.com)** to obtain a return goods authorization number (claim number) and further shipping instructions.

---

### Technical Support

Phone: 604-248-3858

email: [seastar@seastarsolutions.com](mailto:seastar@seastarsolutions.com)

Hours: Monday to Friday 05:00 – 15:30 PST

Web: [www.seastarsolutions.com](http://www.seastarsolutions.com)

---

### Authorized Service Centers & Distributors

For a current listing of all our authorized service centers and distributors please visit our website: [www.seastarsolutions.com](http://www.seastarsolutions.com)

© 2016 MARINE CANADA ACQUISITION INC.  
DBA SEASTAR SOLUTIONS

PRINTED IN CANADA 04/19

Please scan  
this QR code  
and watch our  
latest **Boating  
Safety** video.



**SEASTAR  
SOLUTIONS®**

SEASTAR SOLUTIONS  
3831 NO. 6 ROAD  
RICHMOND, B.C.  
CANADA V6V 1P6

FAX 604-270-7172

**[www.seastarsolutions.com](http://www.seastarsolutions.com)**

**ISO 10592**



FORM NO. 682169 REV. D

