

**SMARTSTICK™**

## MAGNET KIT # HA5479

For use with Yamaha F250-F350 installations & ALL -3 pivot cylinders

### ⚠ CAUTION

Refer to **ALL** Warnings, Cautions and Notices as shown in the SmartStick Installation Instruction Sheet #269064.

### Magnet Installation

1. Mount sensor (Item 1) to steering cylinder following steps 1 – 3 as shown in SmartStick installation instructions included with your SmartStick (Instruction Sheet #269064).

### NOTICE

Use the X dimension shown in THESE instructions to ensure magnet is centered correctly.

### ⚠ CAUTION

**DO NOT** distort the rubber magnet housing when tightening.

2. Mount magnet assembly (Item 2) to the center of the cylinder body and orientate as shown in Figure A. Ensure that arrow (A) is pointing in the same direction as arrow (B) on the SmartStick Sensor. Secure the two hose to the magnet and torque clamp nuts to 10 in.lb. +/-5.

### NOTICE

Failure to have arrow (A) pointing in the same direction as arrow (B) will result in an inactive unit.

3. Continue with steps 5 – 11 as shown in the SmartStick Installation Instructions.

