

Optimus 360 Installation Checklist

- Update Software
 - Color Display
 - Individual Components (mass update)
- Configure System
 - System Type
 - # of Devices
 - Device Locations
- Configure Cylinder
- Purge Hydraulic System
 - Confirm steering direction
 - Confirm port vs starboard connection on PCM
- Calibrate Cylinders
- Confirm Tilt Clearances
- Set Steering Settings
 - Toe Angle
 - Inner/Outer Steering Ratio
 - Low/High Engine RPM
 - Helm Effort
 - Helm Turns
 - Rudder Limits
- Import “Golden File”
 - PCM
 - Joystick
- Joystick Tuning (on water)
 - Tune Joystick
 - Or Verify “Golden File” Tune