

TAP FOR



MAX SPEED & PERFORMANCE IN SECONDS

WITH A PROTAP JACKPLATE CONTROLLER



SEASTAR

PROTAP CONTROLLER

ProTap Controller takes the guesswork out of setting a jackplate height or engine trim every time you get underway. Use ProTap to quickly recall your pre-memorized positions. It works with any jackplate and trim control switch, and allows you to fine tune jackplate and engine trim predictably by moving both in set increments.

- Reach max speed fast with a ProTap controller.
- Provides full tilt engine protection.
- Dual engine support.

www.seastarsolutions.com



SEASTAR
SOLUTIONS®